

*Heaven's Light is Our Guide*  
**Rajshahi University of Engineering and Technology**



**Course Code**  
ECE 3208

**Course Title**  
Communication Engineering Sessional

**Experiment Date:** December 3, 2024,  
**Submission Date:** January 14, 2025

**Lab Report 1:**  
**Analog Signal Transmission and Reception**

**Submitted to**  
Dr. Md. Kamal Hosain  
Professor  
Dept of ETE, RUET

**Submitted by**  
Md. Tajim An Noor  
Roll: 2010025

# Contents

<b>Theory</b>	<b>1</b>
<b>Required Apparatus</b>	<b>2</b>
<b>Block Diagram</b>	<b>2</b>
<b>Procedure</b>	<b>2</b>
<b>Matlab Simulation</b>	<b>3</b>
Code . . . . .	3
<b>Output</b>	<b>5</b>
Experiment Outputs . . . . .	5
Matlab Simulation Outputs . . . . .	5
<b>Discussion</b>	<b>6</b>
<b>Precautions &amp; Conclusion</b>	<b>7</b>
<b>References</b>	<b>7</b>

# Analog Signal Transmission and Reception

## Theory

Analog signal transmission and reception are fundamental concepts in communication engineering. Analog signals are continuous signals that vary over time and can take any value within a given range. These signals are used to transmit information such as audio, video, and other data over various mediums like air, cables, and optical fibers [1]. In this experiment, we focus on Amplitude Modulation (AM) and demodulation.

**Amplitude Modulation (AM):** In AM, the amplitude of the carrier wave is varied in proportion to the information signal. This technique is widely used in radio broadcasting [2].

The reception of analog signals involves demodulation, which is the process of extracting the original information signal from the modulated carrier wave. This is achieved using various demodulation techniques corresponding to the modulation methods used during transmission [2].




Figure 1: Illustration of Signals and Amplitude Modulation (AM)[3]

Analog signal transmission and reception are susceptible to noise and interference, which can degrade the quality of the received signal. Techniques such as filtering and amplification are employed to mitigate these effects and improve signal quality [1].

Overall, understanding analog signal transmission and reception is crucial for designing and analyzing communication systems that rely on analog signals [4].

## Required Apparatus

- Analogue Signal Processing (Model No. DL 3155M60R)
- Oscilloscope
- Connecting Wires

## Block Diagram




Figure 2: Block diagram of Amplitude Modulation and Demodulation.[5]

## Procedure

1. The Analogue Signal Processing board (Model No. DL 3155M60R) was connected to the power supply.
2. An analog signal was generated using the signal generator on the Analogue Signal Processing board.
3. The output of the signal generator was connected to the input of the modulator section on the board.

4. The modulator was set to perform Amplitude Modulation (AM) using the carrier signal provided by the board.
5. The waveform of the message signal and the modulated signal was observed and recorded using the oscilloscope.
6. The output of the modulator was connected to the input of the demodulator section on the board.
7. The modulated signal was demodulated to retrieve the original message signal.
8. The demodulated signal was passed through a filter to remove any noise and interference.
9. The waveform of the demodulated signal was observed and recorded using the oscilloscope.
10. The waveforms of the original message signal, the modulated signal, and the demodulated signal were compared.

## Matlab Simulation

### Code:

The following Matlab code simulates the generation, modulation, and demodulation of an analog signal using Amplitude Modulation (AM).

```
1  % Define parameters
2  Fs = 1000; % Sampling frequency
3  t = 0:1/Fs:1; % Time vector
4
5  % Create message signal
6  Am = 1; % Amplitude of message signal
7  fm = 5; % Frequency of message signal
8  message_signal = Am * sin(2 * pi * fm * t);
9
10 % Create carrier signal
11 Ac = 1; % Amplitude of carrier signal
12 fc = 50; % Frequency of carrier signal
13 carrier_signal = Ac * sin(2 * pi * fc * t);
14
15 % Perform Amplitude Modulation (AM)
16 modulated_signal = (1 + message_signal) .* carrier_signal;
17
18 % Demodulate the signal
19 demodulated_signal = modulated_signal .* carrier_signal;
```

```

20 [b, a] = butter(5, fc/(Fs/2)); % Design a low-pass filter
21 filtered_signal = filter(b, a, demodulated_signal);
22
23 % Plot the signals
24 figure;
25 subplot(4,1,1);
26 plot(t, message_signal);
27 title('Message Signal');
28 xlabel('Time (s)');
29 ylabel('Amplitude');
30
31 subplot(4,1,2);
32 plot(t, carrier_signal);
33 title('Carrier Signal');
34 xlabel('Time (s)');
35 ylabel('Amplitude');
36
37 subplot(4,1,3);
38 plot(t, modulated_signal);
39 title('AM Modulated Signal');
40 xlabel('Time (s)');
41 ylabel('Amplitude');
42
43 subplot(4,1,4);
44 plot(t, filtered_signal);
45 title('Demodulated Signal');
46 xlabel('Time (s)');
47 ylabel('Amplitude');

```

# Output

## Experiment Outputs




Figure 3: Waveform of the Original Message Signal (Yellow) and the Modulated Signal (Blue)




Figure 4: Waveform of the Modulated Signal (Yellow) and the Modulated Signal (Blue) with different message signal




Figure 5: Waveform of the original message signal (Yellow) and the demodulated signal (Blue)

## Matlab Simulation Outputs




Figure 6: Original Message Signal




Figure 7: Carrier Signal




Figure 8: Modulated Signal




Figure 9: Demodulated Signal

## Discussion

The experiment and Matlab simulation demonstrate the process of analog signal transmission and reception using Amplitude Modulation (AM). The original message signal is modulated by varying the amplitude of the carrier signal, resulting in the modulated signal. The modulated signal is then demodulated to retrieve the original message signal.

The waveforms of the original message signal, the modulated signal, and the demodulated signal are observed and compared. The demodulated signal closely resembles the original message signal, demonstrating the effectiveness of the demodulation process.



# Precautions & Conclusion

## Precautions:

- All connections were ensured to be secure before powering on the equipment to avoid short circuits or damage.
- The signal generator settings were verified to ensure the correct frequency and amplitude were used for modulation.
- The oscilloscope probes were handled carefully to avoid damaging the equipment or the circuit.
- Live wires or terminals were avoided to prevent electric shock.
- The modulator and demodulator settings were double-checked to ensure accurate modulation and demodulation.
- The work area was kept clean and organized to prevent accidental disconnections or interference.
- The manufacturer's guidelines for operating the Analogue Signal Processing board and other equipment were followed.

## Conclusion:

Analog signal transmission and reception are essential concepts in communication engineering. The experiment and Matlab simulation provide a hands-on demonstration of Amplitude Modulation (AM) and the demodulation process. By observing the waveforms of the original message signal, the modulated signal, and the demodulated signal, we can understand the impact of modulation and demodulation on analog signals [1].

The experiment highlights the importance of modulation techniques in transmitting information over various communication channels [4]. It also emphasizes the need for demodulation to recover the original message signal from the modulated carrier wave. Overall, analog signal transmission and reception play a vital role in modern communication systems and are fundamental to the field of communication engineering [2].

## References

- [1] S. Haykin, *Communication Systems*. John Wiley & Sons, 2001.
- [2] B. Sklar, *Digital Communications: Fundamentals and Applications*. Prentice Hall, 2001.

- [3] “Draw a diagram of amplitude modulated waves.” Jan. 2025, [Online; accessed 9. Jan. 2025]. [Online]. Available: <https://www.vedantu.com/question-answer/draw-a-diagram-of-amplitude-modulated-waves-class-13-physics-cbse-5f625ed7e5bde9062ff6c68c>
- [4] J. G. Proakis and M. Salehi, *Digital Communications*. McGraw-Hill, 2007.
- [5] T. Arora, M. Gupta, and S. N. Gupta, “An explicit output current-mode quadrature sinusoidal oscillator and a universal filter employing only grounded passive components - a minimal realisation,” *Advances in Electrical and Electronic Engineering*, vol. 19, 10 2021.