

On PCB layout, connect PGND directly to ground connection of input and output capacitors of the charger
A single point connection is recommended between power PGND and the analog GND near the IC PGND pin

Place C6, C7, C8, C9, C11 as close as possible to the IC

