




Best values, not standard values
Will maybe use potentiometers?
TODO: offset to provide correct current limit
given offset from LM334



** Ceramic X5R or X7R

Sheet: /
File: psu.sch

Title: Simple Lab Power Supply

Size: A4 Date: 2019-06-01

KiCad E.D.A. kicad (5.1.2)-1

Rev: A

Id: 1/1