

Vibrations, Structural & Computational Dynamics

October 20th 2020

$$\omega^2 Mx = Kx \Leftrightarrow (K - \lambda M)x = 0$$

ISAE/SUPAERO TOULOUSE
SA403 - ADVANCED COMPUTATIONAL STRUCTURAL MECHANICS

Julien LE FANIC — AIRBUS Structural Engineer / Data Analyst



Table of contents

Scope/Contents

Who am I ?

Reminder

Dynamic Definition

Single dof System

n-dof System

Natural vs. Forced

Time domain vs. frequency domain

Rigid body vs. elastic body

Forced Harmonic State -

General

Forced Harmonic State -

Undamped

Forced Harmonic State -

Damped

Some classical real world examples

Tapei 101 Tower

Chinook Helicopter Ground

Test

A/C Take off

A/C Engine Failure Loads

MAVERIC

Δ Zeroe A/C

ZeroeA/C w/ Propellers

Rotordynamics

Aeroelasticity

Flight Dynamics

Fluid Structure Interaction

Impact

Transition Slides

The FEA Formulation

Basics

Simple bending element

Advanced

Dynamic Reduction

Transient Analysis

Direct Method & Uncertainties

Propagation

The NEWMARK family

integration scheme

Optimization under Dynamics

Constraints

Two Springs/Three Masses

Case Study

Outro & Outcomes

Acknowledgments

References

-

Vibrations, Structural & Computational Dynamics

Scope/Contents

Let's have fun & consider the next topics in more details in the next slides :

- Reminders
- s-dof system
- Industry Flavours of Dynamics Analysis
- Computational Approaches of Dynamics Analysis
- Reduction of Structures for Dynamics Analysis

Vibrations, Structural & Computational Dynamics

Who am I ?

My name is Julien LE FANIC.

My Final Year Engineer Thesis was about hypervelocity Impact*.

I am an AIRBUS Structural Engineer since 2009[†].

Nowadays I spend most of my daily working hours fighting with FEA solver to understand why my dynamic analyses crash and/or/either do not release the expected figures...

*
†
in Paris
in Toulouse

5/67

Reminder

Dynamic Definition




Approach	Keep it simple... but not simpler	... for fun...	... Reality
About dof	s-dof	n-dof	continuum
User's Face			

Table 1: Classification of Dynamic Classical Models vs. Difficulty. In terms of frequency in the range $10^3 - 10^4$ Hz the problem is in the high frequency range, below 10^2 Hz the problem is in the low frequency range. Unfortunately many problems may fall in the in-between.

Nota : The art to switch from a dynamic analysis to a s-dof analysis does exist. For example [Miles' equation](#).

Reminder

Single dof System




Figure 1: Single dof System without Damping device/sketch.

One has from LAGRANGE or D'ALEMBERT principle :

$$m\ddot{x} + c\dot{x} + kx = F \quad . \quad . \quad . \quad . \quad . \quad (3)$$

$$\ddot{x} + 2\xi\omega_0\dot{x} + \omega_0^2 x = \frac{F}{m} \quad . \quad . \quad . \quad . \quad . \quad (4)$$

with the damping factor

$$\xi = \frac{c}{2m\omega_0} \quad . \quad . \quad . \quad . \quad . \quad . \quad (5)$$

And :

$$\omega_0 = \sqrt{\frac{k}{m}} \quad . \quad . \quad . \quad . \quad . \quad . \quad (6)$$

Pulsation
is a very important quantity in Dynamics of Structures.

Reminder

Single dof System




Figure 2: Single dof System with Damping device/sketch.

One has from LAGRANGE or D'ALEMBERT principle :

$$m\ddot{x} + c\dot{x} + kx = F \quad . \quad . \quad . \quad . \quad . \quad (7)$$


$$\ddot{x} + 2\xi\omega_0\dot{x} + \omega_0^2 x = \frac{F}{m} \quad . \quad . \quad . \quad . \quad . \quad (8)$$

with the damping factor

$$\xi = \frac{c}{2m\omega_0} \quad . \quad . \quad . \quad . \quad . \quad . \quad (9)$$

And :

$$\omega_0 = \sqrt{\frac{k}{m}} \quad . \quad . \quad . \quad . \quad . \quad . \quad (10)$$

Pulsation  is a very important quantity in Dynamics of Structures.

[illegible][illegible]

The frequencies f_i are defined as :

[illegible]

Reminder

Natural vs. Forced

A dynamic system is either in :

1. free vibration

- No external excitations $F(t) = 0$
- **Natural** Response/Vibration of the Structure

2. forced vibration

- External excitations $F(t) \neq 0$
 - Either $F(t)$ is periodic (\sim long timescales : many periods)
 - Or $F(t)$ is transient (\sim short timescales)
- **Time** Response in Magnitude and Phase dependent upon the excitation (can be referred as the excitation Spectra)

Reminder

Time domain vs. frequency domain

The response known as frequency analysis is a methode used to compute the answer to oscillations as the ones due to rotations of turbomachinary. It is taken benefit that the excitation is explicitly defined is the frequency.




Figure 3: Phase shift.

The outputs of a frequency analysis are computed as complex numbers. Two different methods can be used in frequency response analysis. The direct method solves the coupled equations of motions in terms of forcing frequency. The modal method uses the mode shapes of the structure to reduce and uncouple the equations of motion : the solution is the sum of the modal responses.

Reminder

Rigid body vs. Elastic body

One can have fun understandings gyroscopic effect and devices that take benefit of the gyroscopic effects...

The main business of complex dynamics phenomena is to bring the modelization towards elastic (at least) solids.

Some solvers can mix rigid & flexible bodies.

Single dof System

Forced Harmonic State - General




Figure 4: Single dof System without Damping device/sketch.

One has from LAGRANGE or D'ALEMBERT principle :

$$m\ddot{x}(t) + c\dot{x}(t) + kx(t) = F(t) \quad . \quad . \quad . \quad (14)$$

and

$$F(t) = F_0 \cos \Omega t = F_0 \mathcal{R} [\exp i\Omega t] \quad . \quad . \quad . \quad (15)$$

The response is the sum of a transient response $x_t(t)$ and a constant response $x_p(t)$:

- $x_t(t)$ is the natural response
- $x_p(t)$ is the response after the transient response has vanished : with a pulsation of same Ω than the excitation and with a magnitude and a phase to be derived

Single dof System

Forced Harmonic State - Undamped




Figure 5: Single dof System.

One has from LAGRANGE or D'ALEMBERT principle :

$$m\ddot{x}(t) + kx(t) = F_0 \cos \Omega t \quad . \quad . \quad . \quad . \quad . \quad (16)$$

One has :

$$x_t(t) = X_t \cos(\omega_0 t - \varphi_t) \quad . \quad . \quad . \quad . \quad . \quad (17)$$

and :

$$x_p(t) = X_p \cos \Omega t \quad . \quad . \quad . \quad . \quad . \quad . \quad (18)$$

inserted in Equation 16 one has the magnitude

$$X_p = \frac{F_0}{k - m\Omega^2} = \frac{1}{\omega_0^2 - \Omega^2} \cdot \frac{F_0}{m} \quad . \quad . \quad . \quad . \quad (19)$$

and of course full solution

$$x(t) = x_t(t) + x_p(t) \quad . \quad . \quad . \quad . \quad . \quad . \quad (20)$$

Nota : Without damping the excitation and the time response are in phase.

Single dof System

Forced Harmonic State - Damped




Figure 6: Single dof System.

One has from LAGRANGE or D'ALEMBERT principle :

$$m\ddot{x}(t) + c\dot{x}(t) + kx(t) = F_0 \cos \Omega t \quad (21)$$

One has :

$$x_t(t) = X_t \exp(-\xi \omega_0 t) \cos(\omega_0 t - \varphi_t) \quad . . . (22)$$

and :

$$x_p(t) = X_p \cos(\Omega t - \varphi_p) \quad (23)$$

inserted in Equation 16 one has the magnitude

$$X_p = \frac{F_0}{m} \cdot \frac{1}{\sqrt{(\omega_0^2 - \Omega^2)^2 + 4(\xi \Omega \omega_0)^2}} \quad (24)$$

$$\varphi_p = \tan^{-1} \frac{2\xi \omega_0 \Omega}{\omega_0^2 - \Omega^2} \quad (25)$$

and of course full solution

$$x(t) = x_t(t) + x_p(t) \quad (26)$$

Nota : amplification of the applied force is maximum when $\Omega \rightarrow \omega_0$.

Forced Harmonic State - Damped

- $$x(t) = \sum_{n=0}^{\infty} x_n(t) = \sum_{n=0}^{\infty} X_n \cos(n\Omega t - \psi_n - \varphi_n) \quad . \quad . \quad . \quad . \quad . \quad . \quad . \quad . \quad . \quad (27)$$

- A set of small navigation icons typically found in Beamer presentations, including symbols for back, forward, search, and other slide controls.

Some classical real world examples

Tapei 101 Tower

Picture from [peellden](#) [2005]



Some classical real world examples

Tapei 101 Tower

Picture from du Pleasis [2010]

Some classical real world examples

Taipei 101 Tower

Situé à Taïwan, la tour Taipei 101 mesure plus de 500 mètres de haut pour une masse totale de près de 700 000 tonnes. Construite en 2003, elle est restée le plus haut gratte-ciel du monde jusqu'en 2007 avec l'inauguration du Burj Dubaï (828 m).

Son TMD est constitué d'une boule d'acier de 660 tonnes pour un rayon de 2,7 m suspendue entre le 92e et le 87e étage. Elle pendule grâce à 4 câbles d'acier de 11,5 m et est amortie par 8 vérins hydrauliques. Sous l'action des typhons, le déplacement des étages les plus hauts peut être de 3 m.

Ainsi, il est prédit par les constructeurs que les oscillations de la tour peuvent être atténuées de 30 % à 40 %. Le système est étudié pour résister à un tremblement de terre de magnitude 7 sur l'échelle de Richter. Son efficacité a été vérifiée lors du séisme Sichuan qui a frappé Taiwan en 2008. De plus, le TMD ne représente que 0.2 % du coût total de construction du bâtiment.

[wikipedia](#) — 2020.

Nota : Further materials... about 2008 Tuned Mass Damper V&V [Oberkampff and Roy \[2010\]](#).



Constructing Taipei 101
from Royce Projects



Constructing Taipei 101
from Royce Projects

Some classical real world examples

Tapei 101 Tower




Figure 7: Single dof System with Damping & Tuned Mass Damper devices. The tuned mass damper basically permits the system of mass m to dissipate energy.

Some classical real world examples

Chinook Helicopter Ground Test

An Helicopter Ground Test that went particularly well.



Copyright © 2014 Airbus Helicopters
All rights reserved.

Some classical real world examples

A/C Take-off

Main loads-drivers for Engine Attachments under a take-off loadcase are :

- Engine Thrust & Torque
- Air Intake F_y & F_z aero resultants @A1



- Inertial $n_z \sim 1.2$
- Overall Aeroloads acting on Nacelle : F_y , F_z and M_x , M_y and M_z
- No sensitivity to A/C precession rate ($\dot{\alpha} \cdot \sum I \cdot \omega$ low means no gyroscopic effect)

Some classical real world examples

A/C Take-off

The F/T A/C parameters allow to find easily the date t for which $\max n_z$ is reached. FT11 $n_z=1.2$ is reached for take-off. Numerical values for illustration purposes.




Figure 8: A330neo FT11 - n_z vs. t .




Figure 9: A330neo FT11 - E/M FM [daN] vs. t .

Some classical real world examples

A/C Engine Failure Loads

Dynamics phenomena involved e.g. within :

- Noise / Pax
- Engine
- Rotorburst
- Imbalance
- Fluid/Structure interaction e.g. Fuel
- and of course many more...

For an A/C an infamous dynamic event is loss of part of an engine as turbomachinery may lose parts to due their wear or whatever... The structure is regulated by two Technical Papers

- CS25.362 (Engine Failure Loads) from CS-25 [EASA \[2018\]](#)
- AMC 25-24 (Sustained Engine Imbalance)

Some classical real world examples

A/C Engine Failure Loads

CS 25.362 Engine failure loads

ED Decision 2009/017/R

- (a) For engine mounts, pylons and adjacent supporting airframe structure, an ultimate loading condition must be considered that combines 1g flight loads with the most critical transient dynamic loads and vibrations, as determined by dynamic analysis, resulting from failure of a blade, shaft, bearing or bearing support, or bird strike event. Any permanent deformation from these ultimate load conditions should not prevent continued safe flight and landing.
- (b) The ultimate loads developed from the conditions specified in paragraph (a) are to be:
 - (1) multiplied by a factor of 1.0 when applied to engine mounts and pylons; and
 - (2) multiplied by a factor of 1.25 when applied to adjacent supporting airframe structure.

[Amdt 25/8]

Figure 10: CS25.362 Flavour.

Some classical real world examples

A/C Engine Failure Loads

4. BACKGROUND.

- a. Requirements. [CS 25.362](#) (“Engine failure loads”) requires that the engine mounts, pylons, and adjacent supporting airframe structure be designed to withstand 1g flight loads combined with the transient dynamic loads resulting from each engine structural failure condition. The aim being to ensure that the aeroplane is capable of continued safe flight and landing after sudden engine stoppage or engine structural failure, including ensuing damage to other parts of the engine.
- b. Engine failure loads. Turbine engines have experienced failure conditions that have resulted in sudden engine deceleration and, in some cases, seizures. These failure conditions are usually caused by internal structural failures or ingestion of foreign objects, such as birds or ice. Whatever the source, these conditions may produce significant structural loads on the engine, engine mounts, pylon, and adjacent supporting airframe structure. With the development of larger high-bypass ratio turbine engines, it became apparent that engine seizure torque loads alone did not adequately define the full loading imposed on the engine mounts, pylons, and adjacent supporting airframe structure. The progression to high-bypass ratio turbine engines of larger diameter and fewer blades with larger chords has increased the magnitude of the transient loads that can be produced during and following engine failures. Consequently, it is considered necessary that the applicant performs a dynamic analysis to ensure that representative loads are determined during and immediately following an engine failure event.

A dynamic model of the aircraft and engine configuration should be sufficiently detailed to characterise the transient loads for the engine mounts, pylons, and adjacent supporting airframe structure during the failure event and subsequent run down.

Figure 11: CS25.362 AMC Flavour - Background.

Some classical real world examples

A/C Engine Failure Loads

5. EVALUATION OF TRANSIENT FAILURE CONDITIONS

- a. Evaluation. The applicant's evaluation should show that, from the moment of engine structural failure and during spool-down to the time of windmilling engine rotational speed, the engine-induced loads and vibrations will not cause failure of the engine mounts, pylon, and adjacent supporting airframe structure. (Note: The effects of continued rotation (windmilling) are described in [AMC 25-24](#)).

Major engine structural failure events are considered as ultimate load conditions, since they occur at a sufficiently infrequent rate. For design of the engine mounts and pylon, the ultimate loads may be taken without any additional multiplying factors. At the same time, protection of the basic airframe is assured by using a multiplying factor of 1.25 on those ultimate loads for the design of the adjacent supporting airframe structure.

- b. Blade loss condition. The loads on the engine mounts, pylon, and adjacent supporting airframe structure should be determined by dynamic analysis. The analysis should take into account all significant structural degrees of freedom. The transient engine loads should be determined for the blade failure condition and rotor speed approved per CS-E, and over the full range of blade release angles to allow determination of the critical loads for all affected components.

The loads to be applied to the pylon and airframe are normally determined by the applicant based on the integrated model, which includes the validated engine model supplied by the engine manufacturer.

The calculation of transient dynamic loads should consider:

- the effects of the engine mounting station on the aeroplane (i.e., right side, left side, inboard position, etc.); and
- the most critical aeroplane mass distribution (i.e., fuel loading for wing-mounted engines and payload distribution for fuselage-mounted engines).

For calculation of the combined ultimate airframe loads, the 1g component should be associated with typical flight conditions.

Figure 12: CS25.362 AMC Flavour - Transient Loads.

Some classical real world examples

A/C Engine Failure Loads

Scope of the analysis. The analysis of the aircraft and engine configuration should be sufficiently detailed to determine the transient and steady-state loads for the engine mounts, pylon, and adjacent supporting airframe structure during the engine failure event and subsequent run-down.

CS-25.362 AMC §6 Analysis Methodology — 2018.

Some classical real world examples

A/C Engine Failure Loads

7. MATHEMATICAL MODELLING AND VALIDATION

- a. Components of the integrated dynamics model. The applicant should calculate airframe dynamic responses with an integrated model of the engine, engine mounts, pylon, and adjacent supporting airframe structure. The model should provide representative connections at the engine-to-pylon interfaces, as well as all interfaces between components (e.g., inlet-to-engine and engine-to-thrust reverser). The integrated dynamic model used for engine structural failure analyses should be representative of the aeroplane to the highest frequency needed to accurately represent the transient response. The integrated dynamic model consists of the following components that must be validated:
 - Airframe structural model.
 - Propulsion structural model (including the engine model representing the engine type-design).

Figure 13: CS25.362 AMC Flavour - Mathematical Modelling.

Some classical real world examples

A/C Engine Failure Loads



Picture from [Rolls-Royce](#) [2014]



Copyright © 2014 Rolls-Royce
All rights reserved.

Some classical real world examples

A/C Engine Failure Loads

Picture from Rolls-Royce [2020]



Some classical real world examples

A/C Engine Failure Loads



Picture from **Rolls-Royce** [2020]

Some classical real world examples

A/C Engine Failure Loads



Downloaded from F. Bueger, Hygrotherm
Wind Noise Project

Some classical (future) real world examples

MAVERIC



Picture from AIRBUS.

Some classical (future) real world examples

Δ Zero



Picture from AIRBUS.

Some classical (future) real world examples

ZeroA/C w/ Propellers



Picture from AIRBUS.

The propeller considered as a minimal discrete dof system clamped at wing can be cast into :

$$\begin{bmatrix} m_1 + m_2 & 0 & 0 \\ 0 & m_1 l_1^2 + m_2 l_2^2 & 0 \\ 0 & 0 & I_2 \end{bmatrix} \begin{Bmatrix} \ddot{x}_1 \\ \ddot{\theta}_1 \\ \ddot{\theta}_2 \end{Bmatrix} + \begin{bmatrix} k_1 & 0 & 0 \\ 0 & k_1 + k_2 & -k_2 \\ 0 & -k_2 & k_2 \end{bmatrix} \begin{Bmatrix} x_1 \\ \theta_1 \\ \theta_2 \end{Bmatrix} = \begin{Bmatrix} 0 \\ 0 \\ 0 \end{Bmatrix} \quad (28)$$

© AIRBUS 2020 - All rights reserved. HVS

supero
SUPAERO

Some classical (future) real world examples

A/C Engine Failure Loads

The propeller dynamics ...

Planned for 2021.

Some classical real world examples

A/C Engine Failure Loads

Engines can lead to e.g. two phenomena linked with flow instabilities :

- Surge
- Stall

Have a look to
[Dixon and Hall \(2013\)](#)
for more insights.

Picture from Airbus



Some classical real world examples

A/C Engine Failure Loads

If one engine is shut down the Aircraft has
to withstand Windmilling Loads.

Picture from Amnis (Same credits as Slide 39/67).



Some classical real world examples

Rotordynamics

References : Lalanne and Ferraris [1998], Muszynska [2005].




Figure 14: A Rotordynamics Simple model. Rotors can be characterized by their structural Modes vs. their rotational speeds ω (CAMPBELL diagram). The bearings \circ can be idealized with the same behaviour of the s-dof system in cylindrical coordinate system. One has to consider the sum of the kinetic energy of the disk, the shaft,... for simple sysem one can reach cloase form solution.

Some classical real world examples

Aeroelasticity

Planned for 2021.


Some classical real world examples

Flight Dynamics

Planned for 2021.

Fluid Structure Interacton

A flavour of Fluid Structure Interaction (e.g. [de Langre \[2001\]](#)).



One can assume e.g. :

[illegible]

One can derive the coupling equations that govern the two parameters (x, F) .

$$M\ddot{F} + KF = M_{SF}\ddot{x} \quad . \quad . \quad . \quad . \quad (30)$$

$$\ddot{x} + x = -m_F S \ddot{F} - m_F \ddot{x} \quad . \quad (31)$$

Figure 15: A Fluid Structure Interaction Simple Configuration. One can easily think e.g. to a bio-fuel tank embedded in a flying machine. Under manoeuvres the bio-fuel is swung.

Inertial coupling does exist for the two parameters (x, F) . One can limit the participation of the fluid to the dynamics of the structure installing anti-swung walls within the tank.

Some classical real world examples

Impact

Planned for 2021.

Transition Slides

So touchy industrial dynamics phenomena could not be solved without massive usage of solvers involving state of the art numerical analysis algorithm.

Basics

One solves POISSON's equation :

[illegible]

It is considered $f \in L^2(\Omega)$. It is assumed $u \in H^2(\Omega)$. Thus by GREEN formula

[illegible]

If it is chosen $v \in H_0^1(\Omega)$ one has

$$\int_{\Omega} \nabla u \cdot \nabla v d\Omega = \int_{\Omega} f v d\Omega \quad , \forall v \in H_0^1(\Omega) (34)$$

The equation (34) is called the variational formulation or the weak form of the differential equation (32).

The FEA Formulation

Basics




Figure 16: Simple axial element assumption sketch

Linear form function

$$\begin{cases} N_1(x) = \frac{1}{l} \left(\frac{l}{2} - x \right) \\ N_2(x) = \frac{1}{l} \left(x + \frac{l}{2} \right) \end{cases} \quad \dots \quad (35)$$

Strain worth

$$\varepsilon = B \begin{bmatrix} u_1 \\ u_2 \end{bmatrix} = \begin{bmatrix} \frac{\partial N_1}{\partial x}, & \frac{\partial N_2}{\partial x} \end{bmatrix} \begin{bmatrix} u_1 \\ u_2 \end{bmatrix} = \begin{bmatrix} -\frac{1}{l}, & \frac{1}{l} \end{bmatrix} \begin{bmatrix} u_1 \\ u_2 \end{bmatrix} \quad \dots \quad \text{ISAE 1986 SUPAERO}$$

The FEA Formulation

Basics

Stiffness matrix is derived as

$$K = \int_{\Omega} B^T E B d\Omega = S \int_{-\frac{l}{2}}^{\frac{l}{2}} \frac{E}{l^2} \begin{bmatrix} 1 & -1 \\ -1 & 1 \end{bmatrix} dx \quad (37)$$

The simple bar element works merely as[†]

$$\begin{Bmatrix} F_1 \\ F_2 \end{Bmatrix} = \frac{ES}{l} \begin{bmatrix} 1 & -1 \\ -1 & 1 \end{bmatrix} \begin{Bmatrix} u_1 \\ u_2 \end{Bmatrix} \quad (38)$$

with stiffness matrix

$$K = \frac{ES}{l} \begin{bmatrix} 1 & -1 \\ -1 & 1 \end{bmatrix} \quad (39)$$

Nota : Mass matrix is derived as

$$M = \frac{\rho S l}{6} \begin{bmatrix} 2 & 1 \\ 1 & 2 \end{bmatrix} \quad (40)$$

Finite Elements Solver User's user can usually output K , M or any matrix in an file for double check

analysis.

[†]

... a $F = k u$ spring ☺

The FEA Formulation

Basics




Figure 17: Simple bending element assumption sketch

For a simple bending element one has the relationship

$$\begin{Bmatrix} F_1 \\ M_1 \\ F_2 \\ M_2 \end{Bmatrix} = \frac{2EI}{l^3} \begin{bmatrix} 6 & -3l & -6 & -3l \\ -3l & 2l^2 & 3l & l^2 \\ -6 & 3l & 6 & 3l \\ -3l & l^2 & 3l & 2l^2 \end{bmatrix} \begin{Bmatrix} v_1 \\ \theta_1 \\ v_2 \\ \theta_2 \end{Bmatrix} \quad (41)$$

The FEA Formulation

Advanced

Planned for 2021.

The FEA Formulation

Dynamic Reduction

Among the most interesting & funny concept within Dynamics FEA is the Model Reduction. On one hand it can be considered as classical business for Static Analysis with the associated GUYAN approach. On the other hand the approach for dynamic analysis is not numerically exact because upon eigenvalues desired dependent. Nevertheless it remains usual business within large companies dynamics analysis. Mainly to ease the exchange of FEM between e.g. stakeholders of a project. I follow Komzsisik [2005] notations.

The FEA Formulation

Dynamic Reduction

For GUYAN Static Reduction the framework is linear elasticity. One solves

[illegible]

with o-set interior degrees of freedom and a-set exterior degrees of freedom one can split the equation (42)

[illegible]

whose first line of (43) means

[illegible]

or

[illegible]

with G_{oa} boundary transformation and u_o^0 fixed boundary displacement.

The FEA Formulation

Dynamic Reduction

Thus the second line of (43) means with the definition (45) of u_o

$$\begin{aligned}
 & K^T_{oa} u_o + K_{aa} u_a = F_a \\
 \Leftrightarrow & K^T_{oa} (u_o^0 + G_{oa} u_a) + K_{aa} u_a = F_a \\
 \Leftrightarrow & \left(\underbrace{K^T_{oa} G_{oa} + K_{aa}}_{\overline{K_{aa}}} \right) u_a = F_a - \underbrace{K^T_{oa} u_o^0}_{\overline{F_a}} \quad \dots \dots \dots (46)
 \end{aligned}$$

with $\overline{K_{aa}}$ boundary stiffness and $\overline{F_a}$ boundary load. Typically with a classical NASTRAN run one has $\overline{K_{aa}} \equiv$ KAAX and $\overline{F_a} \equiv$ PAX. Note that (46) defines the boundary displacement field associated to the ASET (NASTRAN language). For Dynamic framework :

The FEA Formulation

Dynamic Reduction

$$\begin{bmatrix} K_{oo} - \lambda M_{oo} & K_{ot} - \lambda M_{ot} \\ K_{ot}^T - \lambda M_{ot}^T & K_{aa} - \lambda M_{aa} \end{bmatrix} \begin{Bmatrix} u_o \\ u_t \end{Bmatrix} = \begin{Bmatrix} 0 \\ 0 \end{Bmatrix} \quad (47)$$

One considers first the eigenvalue problem :

$$[K_{oo} - \lambda M_{oo}] \Phi_o = 0 \quad (48)$$

One is lead to assume a diagonal matrix $\Lambda_{q_o q_o}$ with q_o the eigenvalues and another matrix $\Phi_{o q_o}$ with classical :

$$\Phi_{o q_o}^T M_{oo} \Phi_{o q_o} = I_{q_o q_o} \quad (49)$$

And for the stiffness :

$$\Phi_{o q_o}^T K_{oo} \Phi_{o q_o} = \Lambda_{q_o q_o} \quad (50)$$

The installed q_o is not today a computational issue for low frequency range of interest for e.g. an Aircraft. It is a gloabl rule of thumb to compute a higher number than in the end the eigenvalues of interest.

The FEA Formulation

Dynamic Reduction

For the boundary

[illegible]

with the coupled boundary Φ_{tq_o} . The dynamics reduction leads to the introduction of the matrix with $q_t + q_o$ columns and with $t + o$ rows.

[illegible]

with $Su_d = u_a$ one has

[illegible]

Thus

[illegible]

Then the problem for the residual structure is :

$$\begin{bmatrix} \Lambda_{q_o q_o} - \lambda I_{q_o q_o} & K_{q_o q_t} - \lambda M_{q_o q_t} \\ K_{q_o q_t}^T - \lambda M_{q_o q_t}^T & \Lambda_{q_t q_t} - \lambda I_{q_t q_t} \end{bmatrix} \begin{Bmatrix} u_{q_o} \\ u_{q_t} \end{Bmatrix} = \begin{Bmatrix} 0 \\ 0 \end{Bmatrix} \quad (55)$$

The FEA Formulation

Dynamic Reduction

with the coupling matrices $M_{q_o q_t}$ and $K_{q_o q_t}$ uilt as previously.

[illegible]

[illegible]

One ends up with a $q_o + q_t$ problem. All the matrices are not square. The nature of the choice of the q_o leads thus to the introduction of a numerical error. This kind of CRAIG- BAMPTON Reduction is not numerically exact for the modal analysis.

Transient Analysis

To solve a time-dependent dynamics problem the engineer has at least the next 4 approaches available :

1. Direct Approach with Explicit scheme
2. Direct Approach with Implicit scheme
3. Modal Superposition in time domain
4. Modal Superposition in frequency domain

The NEWMARK family integration scheme

[illegible]

$$\text{or} \quad M\ddot{u} + C\dot{u} + f_{int} = f_{ext} (59)$$

[illegible][illegible][illegible]

The NEWMARK family integration scheme

$$\dot{u}_{n+1} = \dot{u}_n + (1 - \gamma)\Delta t \ddot{u}_n + \gamma\Delta t \ddot{u}_{n+1} \quad . \quad . \quad . \quad . \quad . \quad . \quad . \quad . \quad (65)$$

$$u_{n+1} = u_n + \Delta t \dot{u}_n + \frac{\Delta t^2}{2} \{ (1 - 2\beta) \ddot{u}_n + 2\beta \ddot{u}_{n+1} \} \quad . \quad . \quad . \quad (66)$$

[illegible]

A random choice of β and γ is not recommended ! They will define the stability of the t -integration scheme. Stability analysis is generally not presented but give a try.

The NEWMARK family integration scheme

[illegible]

Optimization under Dynamics Constraints

Two Springs/Three Masses Case Study

One considers the next Two Springs/Three Masses system. One is interested in the frictionless harmonic answer of the system sketched in Figure 18.




Figure 18: Two Springs/Three Masses system.

Aim of Case study (extracted from Yang [2010]): Choose masses and spring stiffnesses to satisfy next optimization (min-max Danskin [2012]) problem with S and k_0 constants:

$$\text{Problem} \left\{ \begin{array}{l} \min_{p \in \{m_1, m_2, m_3, k_1, k_2\}} \omega = \max \omega_i \\ S = m_1 + m_2 + m_3 \\ m_1 = m_3 \\ k_1 = k_2 \geq k_0 \end{array} \right.$$

Optimization under Dynamics Constraints

Two Springs/Three Masses Case Study

Answer : One can reach the minimum-max ω_i

$$\min \max_i \omega_i = \left\{ \frac{8k_0}{S} \right\}^{\frac{1}{2}} (69)$$

with the *ad hoc* mass split (cf. complete demonstration in Yang [2010]).

Outro & Outcomes

Many topics have been left untouched : do not hesitate by discovering them on your own !

- Dynamics & Instabilities : Flutter, Buffeting, ...
- Component Modal Synthesis
- Dynamics & Nonlinearity
- ...

Acknowledgements

I warmly thank...

- Joseph MORLIER to offer me the possibility to present this lecture
- my ENS - ARTS & MÉTIERS - PARIS VI TACS diploma former colleagues. Mainly those who are Professors of Mechanics Eng. and shared with me their own Slides about *Structural Dynamics*
- my former colleagues & Dynamics Specialists @ DGA/Arcueil
- my nowadays regularly Dynamics Engineers focal points within Engine Manufacturer Companies
- my nowadays Aircraft Dynamics Specialists colleagues @ AIRBUS/Toulouse
- my nowadays Powerplant Integrated FEM Dynamics Specialists colleagues @ AIRBUS/Toulouse

References

I did not copy/paste them only to get a nice Bibliography. I have been lead to open most of them either as a student or in my professional life. Some are really interesting to dive into more insight Structural & Computational Dynamics of Structures and I admit some content chapters, sections & every technical ... To complete the documentation of some finite elements software can be of great help (NASTRAN as [Sitton \[1997\]](#), [Herling \[1997\]](#), ABAQUS, ANSYS, MATLAB, ...)

P.L. Tallec. *Introduction à la dynamique structures*. Les Cours de l'École polytechnique. Ellipses Marketing, 2000. ISBN 9782729879945.

D.A. Wells. *Schaum's Outline of Lagrangian Dynamics*. Schaum's outline series. McGraw-Hill Education, 1967. ISBN 9780070692589.

L. Komzsik. *What Every Engineer Should Know About Computational Techniques of Finite Element Analysis*. What every engineer should know. Taylor & Francis, 2005. ISBN 9780849335631.

M. Roseau. *Vibrations des systèmes mécaniques: méthodes analytiques et applications*. Masson, 1984. ISBN 9782225802058.

M. Géraudin and D.J. Rixen. *Théorie des vibrations: application à la dynamique des structures*. Collection Physique fondamentale et appliquée. Masson, 1996. ISBN 9782225851735.

peeliden. Creative Commons, 2005.

Armand du Plessis. Creative Commons, 2010.

W.L. Oberkampf and C.J. Roy. *Verification and Validation in Scientific Computing*. Cambridge University Press, 2010. ISBN 9781139491761.

EASA. *CS-25*. 2018.

Rolls-Royce. 2014.

Rolls-Royce. 2020.

S.L. Dixon and C. Hall. *Fluid Mechanics and Thermodynamics of Turbomachinery*. Elsevier Science, 2013. ISBN 9780123914101.

M. Lalanne and G. Ferraris. *Rotordynamics Prediction in Engineering*. Wiley, 1998. ISBN 9780471972884.

A. Muszynska. *Rotordynamics*. Mechanical Engineering. CRC Press, 2005. ISBN 9781420027792.

E. de Langre. *Fluides et solides*. Editions de l'Ecole Polytechnique, 2001. ISBN 9782730208338.

Xin-She Yang. *Engineering Optimization: An Introduction with Metaheuristic Applications*. Wiley Online Library: Books. Wiley, 2010. ISBN 9780470640418.

J.M. Danskin. *The Theory of Max-Min and its Application to Weapons Allocation Problems*. Ökonometrie und Unternehmensforschung Econometrics and Operations Research. Springer Berlin Heidelberg, 2012. ISBN 9783642460920.

G. Sitton. *Basics Dynamic Analysis User's Guide*. Msc/NASTRAN, 1997.

D. N. Herling. *Advanced Dynamic Analysis User's Guide*. Msc/NASTRAN, 1997.