

Parallel Bar
PARBAR

Assembly Instructions




How can we improve our assembly instructions?
Your comments and suggestions are important to us.
Please e-mail us at: support@versatables.com.

| | | |
|---|--|---|
|  Plastic Clamp Qty:4 |  Black Wood Screw Qty:8 |  Parallel Bar Qty:1 |
|---|--|---|

Step 1

Clamp


Make sure the table is in flat position. Attach the four Clamps to the corners of the table using (2) two Black Wood Screws for each clamp.



Step 2


Parallel Bar

Place Parallel Bar on the table and tie the loose ends of the wire to the bottom corner knobs.



Step 3

Attach wire to the upper knobs and tighten.



NOTE: Keep this Knob loose until you have finished.

How can we improve our assembly instructions?
Your comments and suggestions are important to us.
Please e-mail us at: support@versatables.com.