


W112 110nm E TUSLI - CHW

CHINA

CHART REFERENCES:

- CH (H/L) 1
- ZBHH (Hohhot) ALT QUICK REF
- ZBAA (Beijing) DEST 1 ALT



SEE INSTRUCTIONS NEXT PAGE

W112 110nm E TUSLI - CHW

ENGINE FAILURE	DEPRESSURIZATION	ENGINE FAILURE + DEPRESSURIZATION
<ul style="list-style-type: none"> • Apply OBSTACLE STRATEGY, • Continue on W112 CHW • At CHW divert to Hohhot (ZBHH) or Beijing (ZBAA) via B215.YBL.A596 	<ul style="list-style-type: none"> • Continue to CHW on W112 • Descend initially FL250, • At 30nm SW CHW descend FL140, • At CHW descend FL100 and divert Hohhot (ZBHH) or Beijing (ZBAA) via B215.YBL.A596 	<ul style="list-style-type: none"> • Apply OBSTACLE STRATEGY, • Continue on W112 CHW • At 30nm SW CHW initiate EMERGENCY DESCENT FL140 • At CHW descend FL100 and divert to Hohhot (ZBHH) or Beijing (ZBAA) via B215.YBL.A596