

**ETIHAD AIRWAYS – UNITED ARAB EMIRATES**

**G325 61nm SW PURPA - PURPA**

ENGINE FAILURE	DEPRESSURIZATION	ENGINE FAILURE + DEPRESSURIZATION
<ul style="list-style-type: none"> <li>• Apply <b>OBSTACLE STRATEGY</b>.</li> <li>• Continue to SCH via G325. PURPA. B215,</li> <li>• AT SCH divert on A364 to Kashi (ZWSH)</li> </ul> <p style="text-align: center;"><b>OR</b></p> <ul style="list-style-type: none"> <li>• At “SCH” track direct to HTN VOR and Divert to Hotan (ZWTN).</li> </ul>	<ul style="list-style-type: none"> <li>• Continue to SCH</li> <li>• Descend initially FL290,</li> <li>• 16nm SW PURPA descend FL250,</li> <li>• At 45nm from SCH descend FL140</li> <li>• At SCH descend FL100 and divert on A364 to Kashi (ZWSH)</li> </ul> <p style="text-align: center;"><b>OR</b></p> <ul style="list-style-type: none"> <li>• At SCH, descend to FL100 and track direct to HTN VOR and Divert to Hotan (ZWTN).</li> </ul>	<ul style="list-style-type: none"> <li>• Apply <b>OBSTACLE STRATEGY</b>,</li> <li>• Continue to SCH via G325. PURPA. B215,</li> <li>• Descend maintain FL250 until 45NM to SCH</li> <li>• At 45NM from SCH, initiate <b>EMERGENCY DESCENT</b> FL140,</li> <li>• At SCH, descend FL100 and divert on A364 to Kashi (ZWSH)</li> </ul> <p style="text-align: center;"><b>OR</b></p> <ul style="list-style-type: none"> <li>• At SCH descend FL100 and track direct to HTN VOR and Divert to Hotan (ZWTN).</li> </ul>