

-

G325 B215 61nm SW PURPA - SCH

ENGINE FAILURE	DEPRESSURIZATION	ENGINE FAILURE + DEPRESSURIZATION
<ul style="list-style-type: none"> • Apply OBSTACLE STRATEGY. • Continue to SCH via G325. PURPA. B215 • AT SCH divert on A364 to Kashi (ZWSH) <p style="text-align: center;">OR</p> <ul style="list-style-type: none"> • At “SCH” track direct to HTN VOR and Divert to Hotan (ZWTN). 	<ul style="list-style-type: none"> • Continue to SCH • Descend initially FL290, • 16nm SW PURPA descend FL250, • At 45nm from SCH descend FL140 • At SCH descend FL100 and divert on A364 to Kashi (ZWSH) <p style="text-align: center;">OR</p> <ul style="list-style-type: none"> • At SCH, descend to FL100 and track direct to HTN VOR and Divert to Hotan (ZWTN). 	<ul style="list-style-type: none"> • Apply OBSTACLE STRATEGY, • Continue to SCH via G325. PURPA. B215, • Descend maintain FL250 until 45nm to SCH • At 45NM from SCH, initiate EMERGENCY DESCENT FL140, • At SCH, descend FL100 and divert on A364 to Kashi (ZWSH) <p style="text-align: center;">OR</p> <ul style="list-style-type: none"> • At SCH descend FL100 and track direct to HTN VOR and Divert to Hotan (ZWTN).