



**W112 48nm W AKTOB - TUSLI**

**IF DIVERTING TO URUMQI (ZWWW)**

ENGINE FAILURE	DEPRESSURIZATION	ENGINE FAILURE + DEPRESSURIZATION
<ul style="list-style-type: none"> <li>• Apply <b>OBSTACLE STRATEGY</b>,</li> <li>• Turn direct to HMI</li> <li>• At HMI divert Urumqi (ZWWW) via HMI.B215.GREN2, LIGHT, FKG and URC.</li> </ul>	<ul style="list-style-type: none"> <li>• Turn direct to HMI,</li> <li>• Descend initially FL250,</li> <li>• At 195nm from HMI descend FL100</li> <li>• At HMI divert to Urumqi (ZWWW) via HMI.B215.GREN2, LIGHT, FKG and URC.</li> </ul>	<ul style="list-style-type: none"> <li>• Apply <b>OBSTACLE STRATEGY</b>,</li> <li>• Turn direct to HMI,</li> <li>• At 195nm from HMI initiate <b>EMERGENCY DESCENT</b> FL100</li> <li>• At HMI divert to Urumqi (ZWWW) via HMI.B215.GREN2, LIGHT, FKG and URC.</li> </ul>