


G325 PS - 61nm SW PURPA

PAKISTAN

CHART REFERENCES:

- ME/CH (H/L) 5
- OPPS (Peshawar) DEST 1 ALT MES
- OPRN (Islamabad) DEST 1 ALT MES



SEE INSTRUCTIONS NEXT PAGE

G325 PS - 61nm SW PURPA

ENGINE FAILURE	DEPRESSURIZATION	ENGINE FAILURE + DEPRESSURIZATION
<ul style="list-style-type: none"> • Start the turn, • Apply OBSTACLE STRATEGY, • Return on G325 to PS and divert to Peshawar (OPPS) or Islamabad (OPRN). 	<ul style="list-style-type: none"> • Start the turn, • Descend initially FL290, • Return to PS on G325, • 4NM NE GT descend FL200, • At 100NM NE PS descend FL140 and continue, • At 50NM NE PS descend FL100 and divert to Peshawar (OPPS) or Islamabad (OPRN). 	<ul style="list-style-type: none"> • Start the turn, • Apply OBSTACLE STRATEGY, • Return to PS on G325 • 4NM NE GT initiate EMERGENCY DESCENT FL200, and continue PS on G325. • At 100NM NE PS descend FL140 and continue PS • At 50NM NE PS descend FL100 and divert to Peshawar (OPPS) or Islamabad (OPRN).