



The Viewfinder



1	Focus points	12	Flash compensation indicator
2	Focus indicator	13	Exposure compensation indicator
3	Autoexposure (AE) lock indicator	14	Auto ISO sensitivity indicator
4	Shutter speed	15	Number of exposures remaining
5	Aperture (f-number)		Number of shots remaining before memory
6	Battery indicator		buffer fills
7	Bracketing indicator		White balance recording indicator
8	"K" (appears when memory remains for over		Exposure compensation value
	1,000 exposures)		Flash compensation value
9	Flash-ready indicator		Capture mode indicator
10	Flexible program indicator		ISO sensitivity
11	Exposure indicator	16	Warning indicator
	Exposure compensation display		
	Electronic rangefinder		

☒ **The Viewfinder**

The response time and brightness of the viewfinder display may vary with temperature.