

Cable Management

The following offers guidelines to installing Schletter cable management clips and accessories. Schletter offers simple snap-on clips for quick and easy cable management.

Product Features


- Quick and simple
- UV resistance
- Cable protection

*Please note: cable management should always be installed after the mounting system is assembled and **before modules are in place on the rack**.

Proklip-S Cable Clip

For use with Profile Series 05


1. Snap clip into M8 screw duct of rail as shown in image.
2. Slide clip to desired position.



Proklip-C Cable Clip

For use with Solo05 and Profi05 rails


1. Hook top part of clip into the side of M8 screw duct of rail.
2. Slide clip to desired position.
3. Snap bottom part of clip onto bottom part of rail.



Proklip2000-B Cable Clip

For use with BF Rail and T-Rail Series

1. Snap clip into M10 screw duct on side of rail as shown in image.
2. Slide clip to desired position.



Proklip2000-P Cable Clip

For use with S-Rail Series and KP-Rail Series


1. Snap clip onto side of rail as shown in image.
2. Slide clip to desired position.



Proklip-Q Cable Clip

For use with S-Rail Series and KP-Rail Series

1. Snap clip onto desired position of rail as shown in image.



Proklip-F Cable Tube Clip

For use with FS system or FS Uno™ posts

1. After FS posts are installed, but before installing the head assembly, slide clip down onto post from end as shown in image.
2. Gently tap clip with a rubber mallet to desired position.

When installing conduit, slide conduit up through the clips and into desired position.




Proklip-F




Cable Duct With Edge Protectors

For use with S-Rail and FixZ Rail Series

1. Place cable duct against side of rail as shown in image.
2. Attach cable duct to rail with self-drilling screws spaced two feet apart.



Cable duct




Assembly view

Edge Protection

For use with cable ducts


1. Insert plastic edge protection onto cable duct ends.
2. Tap plastic edge protection gently with rubber mallet to secure onto cable duct.



Combiner Box Mount

Combiner box mount can be installed onto FS post or rear strut on a PvMax. Each kit includes two identical top and bottom brackets. Combiner box is not included.

1. Locate mounting points on back wall of combiner box.
2. Attach Solo rail to combiner box using M8 bolt, washer, nut, and KlickIn components.
3. Fasten threaded rod to Solo rail using square nut, and flange nut; place end caps.
4. Once top and bottom brackets are installed, position combiner box to post/rear strut; place EPDM strip between post/rear strut and Solo rail.
5. Secure top and bottom brackets by inserting exposed end of threaded rods into pre-punched holes on angle bracket then fasten using flange nuts; place EPDM strip between post/strut and angle bracket.



Combiner Box Mount Components

1. M8 bolt
2. Washer
3. Square nut
4. KlickIn component
5. Solo rail
6. End cap
7. EPDM rubber strip
8. Flange nut
9. Threaded rod, 3/8"
10. Angle bracket



Combiner box attached to FS post with mount

**For more information on cable management,
please contact us at:**

Schletter Inc.
1001 Commerce Center Drive
Shelby, NC 28150
Call: (888) 608 - 0234
Fax: (704) 595 - 4210
info.us@schletter-group.com

Schletter Canada Inc.
3181 Devon Drive
Windsor, ON N8X 4L3
Call: (519) 946 - 3800
Fax: (519) 946 - 3805
mail.canada@schletter-group.com