

Steps defined for possible solution in error 12

Does this solve the problem?

1] Yes

2] No

3] I don't know

- **Explanation**

The errors 12, 13 & 14 are identical.

12 – Grid drop voltage L1 – V82

13 – Grid drop voltage L2 – V82

14 – Grid drop voltage L3 – V82

The possible steps to solve these errors are explained in the guide for 12.

Relevant troubleshooting guide
Description
12 – Grid drop voltage L1 – V82