

After producing a resin mold, the PDMS stamp can be manufactured. Some points that should be kept in mind while producing the stamp:

- If the mold was designed with only two of the four walls to allow for easy stamp removal, tape should be used to form temporary walls during the pouring and curing process
  - The molds provided by Bender et al. in the GitHub repository are designed in this fashion
- Curing time in the oven will affect stamp stiffness; a longer curing time will lead to a stiffer stamp