


Sheet: /
File: dart-hat.sch

Title:

Size: A4 Date:
KiCad E.D.A. kicad 5.1.5+dfsg1-2build2

Rev:
Id: 1/7




Sheet: /Can Interface/
File: can_iface.sch



Title:

Size: A4
KiCad E.D.A. kicad 5.1.5+dfsg1-2build2

Date:

Rev:
Id: 2/7





NOTES: bmi088 driver has DRDY wired to gpio26 (pin 6 on wiringpi)
- i2c should be easier but i'm going for SPI since the old implementation works
- shuttle has interrupt pin jumper
- might want to not only expose the jumper for this, but also tie in 2 separate GPIO pins with the 2.54mm headers on each interrupt so i can manually connect interrupt pins?

IMPORTANT: review the SPI initialization behavior (6.1, p45, bmi088 datasheet)
- looks like GND on PS sets gyro to SPI mode
- giving a rising edge on the CS pin for the accel switches it to spi mode. this can be done via a dummy read/write operation

Sheet: /IMU/
File: IMU.sch

Title:


Size: A4

Date:

KiCad E.D.A. kicad 5.1.5+dfsg1-2build2


Rev:

Id: 4/7



TODO:

- reverse voltage protection (backcurrent)
- decoupling
- fuses
- power setup



Sheet: /Servo Driver/
File: servo_driver.sch

Title:


Size: A4

Date:


KiCad E.D.A. kicad 5.1.5+dfsg1-2build2

Rev:

Id: 5/7



Sheet: /3v3_supply/ File: 3v3_supply.sch		
Title:		
Size: A4	Date:	Rev:
KiCad E.D.A. kicad 5.1.5+dfsg1-2build2		Id: 6/7



Sheet: /5V Power Supply/
File: 5V_Power_Supply.sch

Title:

Size: A4 Date:
KiCad E.D.A. kicad 5.1.5+dfsg1-2build2

Rev:
Id: 7/7