


3. Install Micro:bit Driver:

Link micro:bit board with computer by micro USB cable, then open the link : <https://fs.keyestudio.com/KS4003-4004> to download the driver of Micro:bit main board.




mbed_usb_2020_x64_1212.exe


Double click after downloading the driver.




Then click "Next"



The following page pops up and click "install"





Tap "Finish" . Then click "Computer" —> "Properties" —> "Device manager" , as shown below.

