



Please Call First!

DO NOT RETURN TO STORE

Need help with assembly? Missing or broken parts?

Business Hours: M-F 8am-5pm PST

Toll Free: 1 (866) 632-6632 support@slambrands.com

ARIEL

WIDE TV STAND

Assembly Instructions
Item #221053



IMPORTANT INFORMATION

Read carefully before assembling TV Stand.
Keep these instructions for further use.



CAUTION!

This TV Stand is intended for use only with the products and maximum weights indicated. Use with other products or products heavier than maximum weights indicated may result in instability causing possible injury.


Model: 221053

Distribution / Manufacturer: Slam Brands, Inc.

Country of Origin: China

Manufacture Date: 02.15.07

Accommodates Most:




DLP/LCD Projection



Plasma/LCD

Component Shelf:

A maximum load weight of 36.28kg /80 lbs.



Television Shelf:

A maximum of a 56" DLP/LCD Projection or a 60" Plasma/LCD. A maximum TV shelf load weight of 81.64kg /180lbs.

Toll Free: 1 (866) 632-6632 Email: support@slambrands.com Business Hours: M-F 8am-5pm PST



SLAM BRANDS, INC
2260 152nd Ave NE
Redmond, WA 98052
www.slambrands.com


SAFETY FIRST

- ! When moving TV Stand, remove TV first.
Do NOT move TV Stand with a TV on top
- ! TVs are front heavy. Place TV as far from front surface of stand as possible.
- ! To avoid injury, assemble TV Stand in final location. Moving the stand after assembled is not recommended.




AVIO Entertainment Furnishings is a trademark of Slam Brands, Inc.


ASSEMBLY OVERVIEW




PARTS IDENTIFICATION




① Base (1)




② L/R support (2)




③ Rear support (1)



④ Support frame (1)



⑤ Top glass (1)




⑥ Shelf glass (1)




AVIO™

AVIO Entertainment Furnishings is a trademark of Slam Brands, Inc.


HARDWARE IDENTIFICATION




Ⓐ Feet (6)




Ⓑ Large screw (4)




Ⓒ Large washer (4)




Ⓓ Small screw (4)




Ⓔ Small washer (4)




Ⓕ Rubber bumper(4)




Ⓖ Wood screw (1)



Ⓗ Drywall anchor (1)




Ⓘ Small allen key (1)



Ⓙ Large allen key (1)

ATTACH FEET




Requirements

This step requires
6 X Feet (A)

Attach Feet (A) to Base (1)


1



AVIO™


AVIO Entertainment Furnishings is a trademark of Slam Brands, Inc.

ATTACH L/R SUPPORTS and REAR SUPPORT




Attach L/R Support (2) and Rear Support (3) to Base (1)

2




Note: Tighten screws (B) securely after finishing step (3).

ATTACH SUPPORT FRAME



Attach Support Frame (4) to L/R Support (2) and Rear Support (3)


3



AVIO™

AVIO Entertainment Furnishings is a trademark of Slam Brands, Inc.


ATTACH RUBBER BUMBERS



Requirements
This step requires 4 X
Rubber bumpers (F)

Attach Rubber Bumpers (F) to Rear Support (3) and Support Frame (4)


4



ATTACH TOP GLASS and SHELF GLASS

Attach Top Glass (5) and Shelf Glass (6) to Support Frame (4)



5



AVIO™

AVIO Entertainment Furnishings is a trademark of Slam Brands, Inc.

Attach Wall Bracket

	Requirements This step requires 1 x Wood screw (G) , 1 x Drywall anchor (H) and A screw-driver	
---	--	---

Attach Wall Bracket

6

