

Sheet: /
File: kiisumini.kicad_sch

Title:


Size: A4

Date:

KiCad E.D.A. 9.0.6

Rev:

Id: 1/11



Sheet: /Core/
File: core.kicad_sch

Title:


Size: A4

Date:

Rev:

KiCad E.D.A. 9.0.6

Id: 2/11



Sheet: /CC1101/
File: cc1101.kicad_sch

Title:


Size: A4
KiCad E.D.A. 9.0.6

Date:

Rev:

Id: 3/11

Rev:
Id: 5/11



Sheet: /Power/
File: power.kicad_sch

Title:


Size: A4

Date:


KiCad E.D.A. 9.0.6

Rev:


Id: 6/11



Sheet: /Buttons/ File: buttons.kicad_sch		
Title:		
Size: A4	Date:	Rev:
KiCad E.D.A. 9.0.6	Id: 6/11	



Id: 8/11



Sheet: /Periphery/
File: periphery.kicad_sch

Title:


Size: A4

Date:

KiCad E.D.A. 9.0.6

Rev:

Id: 9/11



Sheet: /SD Card/
File: sd_card.kicad_sch

Title:

Size: A4

Date:

KiCad E.D.A. 9.0.6

Rev:

Id: 10/11

