




คู่มือการใช้งาน
อุปกรณ์รับชำระเงินด้วย QR Code “พร้อมรับ”


การติดตั้ง

 <p>The diagram shows the back of a green device. At the top right is a black circular 'Reset' button. Below it is a grey rectangular area with a yellow dot and a black 'Antenna' label with a signal icon. At the bottom left is a power port labeled 'Main' with a '12V.' adaptor connected to it. Above the port is an 'Acc' label with a battery icon.</p>	 <p>The four screenshots show the device screen during calibration. The screen is black with a red border. The text 'Touch Corners as Indicated' is at the top. The bottom of the screen has three circular icons. The corners of the screen are marked with red lines and arrows indicating where to touch for calibration.</p>
<ol style="list-style-type: none">1. ต่อสายเสาอากาศเข้าที่ช่อง Antenna2. ต่อสายไฟจาก Adaptor 12V. เข้าที่ช่อง Main3. กดปุ่ม Reset ค้างไว้ประมาณ 10-15 วินาที จนกระทั่งหน้าจอแสดงข้อความ "Touch Corners as Indicated "	<ol style="list-style-type: none">4. กดตามจุดที่ถูกระบุทั้ง 4 มุม ของหน้าจอ เพื่อทำการ Calibrate หน้าจอ



5. เลือกโหมดการทำงานที่ต้องการ Attended / Unattended จากนั้นให้เลือก Set Up WIFI เพื่อเข้าสู่หน้าจอการตั้งค่าการเชื่อมต่อ WIFI



6. เลือกอุปกรณ์ WIFI ที่ต้องการเชื่อมต่อ แล้วใส่รหัสผ่าน (Password) ในช่อง PWD แล้วกดปุ่มเครื่องหมายถูก  บนแป้นพิมพ์

	
<p>7. กด “ใช่” เพื่อบันทึกค่าการทำงานของ WIFI หรือ กด “ยกเลิก” เพื่อยกเลิกการกำหนดค่าการทำงานของ WIFI</p>	<p>8. รอสักครู้...อุปกรณ์กำลังทำการเชื่อมต่อสัญญาณ WiFi</p>
 <p>ยินดีต้อนรับ (Welcome)</p>	