


Current draw during “Off” state due to pull-up resistors **R4** and **R25**.

Pull-down resistor on BL652 module cannot be disabled causing unnecessary quiescent current draw.



Remove **R4**
and **R25** SMT
resistors.