

1

MCU Signal Logic HIGH (Phase NORMAL) = 3V3
MCU Signal Logic LOW (Phase REVERSAL) = 0V

When motor is active, input voltage range is battery voltage: 12-16.8V. Voltage divider scales input voltage to 3-4.2V.

A



C

D

A