




PawBox Documentation



Web: pawbox.com.ar

Analog Stick Diagram:


Normal Version




Hall Version



Símbolo del pulsador




Estos contactos horizontales son el mismo




Fijese en el ancho de las láminas de contacto

Wiring for pawBox V0 Firmware:

Wiring for pawBox V1,V4 Firmware:




Wiring for pawBox V2,V3,V5 Firmware:



Possible Layouts:


Firmware: pawBox_v0
HitStick Layout



Hidden Button:

$\square + \triangleright = \text{PS}$


Firmware: pawBox_v1
HitStick Layout + RS



Hidden Button:

$\square + \triangleright = \text{PS}$

Firmware: pawBox_v2
Devil May Cry Layout




Hidden Buttons:

$\square + \triangleright = \text{PS}$

$\text{L3} + \text{R3} + \text{L2} = \triangleright$

$\text{L3} + \text{R3} + \text{R2} = \square$

Firmware: pawBox_v2
Stellar Blade Layout



Hidden Buttons:

$\square + \triangleright = \text{PS}$










$\text{L3} + \text{R3} + \text{L2} = \triangleright$

$\text{L3} + \text{R3} + \text{R2} = \square$

Generic Functions:

Included in all pawBox firmware versions.

Socd Modes:

| Activation: | Left + Right | Down + Up |
|---|--|---|
| Hold for over 3 secs: L3+R3+Square |  A red square with a black paw print in the center, followed by a plus sign, another red square with a black paw print in the center, followed by an equals sign, and a red octagonal stop sign with a black paw print in the center and the word "STOP" below it. |  A red square with a black paw print in the center, followed by a plus sign, another red square with a black paw print in the center, followed by an equals sign, and a red octagonal stop sign with a black paw print in the center and the word "STOP" below it. |
| Hold for over 3 secs: L3+R3+Triangle |  A red square with a black paw print in the center, followed by a plus sign, another red square with a black paw print in the center, followed by an equals sign, and a red right-pointing arrow.  A red square with a black paw print in the center, followed by a plus sign, another red square with a black paw print in the center, followed by an equals sign, and a red left-pointing arrow. <small>1ST 2ND</small> <small>2ND 1ST</small> |  A red square with a black paw print in the center, followed by a plus sign, another red square with a black paw print in the center, followed by an equals sign, and a red up-pointing arrow. |
| Hold for over 3 secs: L3+R3+Cross |  A red square with a black paw print in the center, followed by a plus sign, another red square with a black paw print in the center, followed by an equals sign, and a red octagonal stop sign with a black paw print in the center and the word "STOP" below it. |  A red square with a black paw print in the center, followed by a plus sign, another red square with a black paw print in the center, followed by an equals sign, and a red up-pointing arrow. |
| Hold for over 3 secs: L3+R3+Circle |  A red square with a black paw print in the center, followed by a plus sign, another red square with a black paw print in the center, followed by an equals sign, and a red octagonal stop sign with a black paw print in the center and the word "STOP" below it. |  A red square with a black paw print in the center, followed by a plus sign, another red square with a black paw print in the center, followed by an equals sign, and a red down-pointing arrow. |

Analog or Digital:


| Analog | Digital |
|-----------------------------------|-----------------------------------|
| Hold for over 3 secs: L3+R3+R1 | Hold for over 3 secs: L3+R3+L1 |

Special Functions:

God of War Mode:


Included in pawBox V3 and V5

Firmware: pawBox_v3
God of War Mode



Hidden Buttons:
□ + ▢ = PS
L3 + R3 + L2 = ▢
L3 + R3 + R2 = □

Firmware: pawBox_v3
Normal Mode




Hidden Buttons:
□ + ▢ = PS
L3 + R3 + L2 = ▢
L3 + R3 + R2 = □

| God of War Mode | Normal Mode |
|-----------------------------------|-------------------------------------|
| Hold for over 3 secs: L3+R3+Up | Hold for over 3 secs: L3+R3+Down |

Ambidextrous Solution:


Included in pawBox V4 and V5

Firmware: pawBox_v4
Left Handed Mode



Hidden Buttons:
 $\square + \triangleright = \text{PS}$
 $\text{L3} + \text{R3} + \text{L2} = \triangleright$
 $\text{L3} + \text{R3} + \text{R2} = \square$

Firmware: pawBox_v4
Right Handed Mode




Hidden Buttons:
 $\square + \triangleright = \text{PS}$
 $\text{L3} + \text{R3} + \text{L2} = \triangleright$
 $\text{L3} + \text{R3} + \text{R2} = \square$

| Left Handed Mode | Right Handed Mode |
|--------------------------------------|-------------------------------------|
| Hold for over 3 secs: L3+R3+Right | Hold for over 3 secs: L3+R3+Left |

Rotation:

Included in pawBox V5



| Left Rotation | Right Rotation |
|-----------------------------------|-----------------------------------|
| Hold for over 3 secs: L3+R3+L2 | Hold for over 3 secs: L3+R3+R2 |

To go back to normal mode activate any Socd Mode like: L3+R3+Square

[rotation documentation here](#)