




PawBox Documentation



Web: pawbox.com.ar

Analog Stick Diagram:


Normal Version




Hall Version



Símbolo del pulsador




Estos contactos horizontales son el mismo




Fijese en el ancho de las láminas de contacto


Wiring for pawBox V0 Firmware:



Wiring for pawBox V1,V4 Firmware:




Wiring for pawBox V2,V3,V5 Firmware:



Possible Layouts:


Firmware: pawBox_v0
HitStick Layout



Hidden Button:

$\square + \triangle = \text{PS}$


Firmware: pawBox_v1
HitStick Layout + RS



Hidden Button:

$\square + \triangle = \text{PS}$

Firmware: pawBox_v2
Devil May Cry Layout



Hidden Buttons:

$\square + \triangle = \text{PS}$

$\text{L3} + \text{R3} + \text{L2} = \triangle$

$\text{L3} + \text{R3} + \text{R2} = \square$

Firmware: pawBox_v2
Stellar Blade Layout



Hidden Buttons:

$\square + \triangle = \text{PS}$










$\text{L3} + \text{R3} + \text{L2} = \triangle$

$\text{L3} + \text{R3} + \text{R2} = \square$

Generic Functions:

Included in all pawBox firmware versions.

Socd Modes:

Activation:	Left + Right	Down + Up
Hold for over 3 secs: L3+R3+Square	 A red square with a black paw print in the center, followed by a plus sign, another red square with a black paw print in the center, followed by an equals sign, and a red octagonal stop sign with a black paw print in the center and the word "STOP" below it.	 A red square with a black paw print in the center, followed by a plus sign, another red square with a black paw print in the center, followed by an equals sign, and a red octagonal stop sign with a black paw print in the center and the word "STOP" below it.
Hold for over 3 secs: L3+R3+Triangle	 A red square with a black paw print in the center, followed by a plus sign, another red square with a black paw print in the center, followed by an equals sign, and a red right-pointing arrow.  A red square with a black paw print in the center, followed by a plus sign, another red square with a black paw print in the center, followed by an equals sign, and a red left-pointing arrow. <small>1ST 2ND</small> <small>2ND 1ST</small>	 A red square with a black paw print in the center, followed by a plus sign, another red square with a black paw print in the center, followed by an equals sign, and a red up-pointing arrow.
Hold for over 3 secs: L3+R3+Cross	 A red square with a black paw print in the center, followed by a plus sign, another red square with a black paw print in the center, followed by an equals sign, and a red octagonal stop sign with a black paw print in the center and the word "STOP" below it.	 A red square with a black paw print in the center, followed by a plus sign, another red square with a black paw print in the center, followed by an equals sign, and a red up-pointing arrow.
Hold for over 3 secs: L3+R3+Circle	 A red square with a black paw print in the center, followed by a plus sign, another red square with a black paw print in the center, followed by an equals sign, and a red octagonal stop sign with a black paw print in the center and the word "STOP" below it.	 A red square with a black paw print in the center, followed by a plus sign, another red square with a black paw print in the center, followed by an equals sign, and a red down-pointing arrow.

Analog or Digital:


Analog	Digital
Hold for over 3 secs: L3+R3+R1	Hold for over 3 secs: L3+R3+L1

Special Functions:

God of War Mode:


Included in pawBox V3 and V5

Firmware: pawBox_v3
God of War Mode



Hidden Buttons:
square + triangle = PS
L3 + R3 + L2 = right arrow
L3 + R3 + R2 = square

Firmware: pawBox_v3
Normal Mode




Hidden Buttons:
square + triangle = PS
L3 + R3 + L2 = right arrow
L3 + R3 + R2 = square

God of War Mode	Normal Mode
Hold for over 3 secs: L3+R3+Up	Hold for over 3 secs: L3+R3+Down

Ambidextrous Solution:

Included in pawBox V4 and V5


Firmware: pawBox_v4
Left Handed Mode



Hidden Buttons:

+ = PS
 + + =
 + + =

Firmware: pawBox_v4
Right Handed Mode




Hidden Buttons:

+ = PS
 + + =
 + + =

Left Handed Mode	Right Handed Mode
Hold for over 3 secs: L3+R3+Right	Hold for over 3 secs: L3+R3+Left

Included in pawBox V5



To go back to normal mode activate any Socd Mode like: L3+R3+Square

rotation documentation here