




NOTES:

1. GLUE OR EPOXY JOINTS TOGETHER WHILE MAKING SURE THE FRAME IS CLAMED FLAT.

2. MAKE SURE ALL 4 SECTIONS ARE ASSEMBLED SO THE POCKET FOR SENSORS ARE UP.



1
4X



1	4	FET-0201		FRONT FRAME SECTION		PLYWOOD			-	
ITEM NO.	QTY.	PART NUMBER		PART DESCRIPTION		MATERIAL		FINISH	NOTE NO.	
				UNLESS OTHERWISE SPECIFIED:		DRAWN	NAME	DATE	freETarget TITLE: FRONT FRAME CLAMP	
				DIMENSIONS ARE IN INCHES		J. SNAPP	16 MAY 25			
				TOLERANCES:		CHECKED				
				FRACTIONAL ±		ENG APPR.				
				ANGULAR: MACH ±		MFG APPR.				
				BEND ±						
				TWO PLACE DECIMAL ±						
				THREE PLACE DECIMAL ±						
				INTERPRET GEOMETRIC TOLERANCING PER:		Q.A.				
				MATERIAL		COMMENTS:				
FET-0200		freETarget						SIZE	DWG. NO.	REV
								D	FET-0201	