

## AERODROME CHART

29° 10' 42.252" N  
075° 45' 17.045" E



ELEV. 701ft

TWR 122.5

## HISAR, INDIA

HISAR AIRPORT

RWY	DIRECTION	THR CO-ORDINATES	THR ELEV	BEARING STRENGTH	
12	120°	29°10'55.477"N 075°45'0.549"E	701	8/F/C/W/T	<ul style="list-style-type: none"><li>DATUM: WGS 84</li><li>DIMENSION IN METERS</li><li>ELEVATIONS IN FEET</li><li>RUNWAY BEARING ARE MAGNETIC</li></ul>
30	300°	29°10'35.484"N 075°45'39.0292"E	701		

ANNUAL RATE OF  
CHANGE 2' EDATE OF AERONAUTICAL INFORMATION  
NOVEMBER 2018

Airports Authority of India, Cartography Unit.

UPDATED AS ON 25.09.2019