

General Aviation

- Aircraft to be towed to the designated position (marked engine start up) provided to the west of TWY 'Q' facing east. After positioning the aircraft on the said marking, pilot will obtain start-up clearance from ATC.
- Taxi out via TWY Q/ TWY F4

