

LVP TAXI ROUTING – EASTERLY FLOW – RWY 11R, RWY 11L & RWY 10

ARP 28° 34' 07"N  
077° 06' 44"E

ELEVATION 778 Ft

TWR RWY 09/27 - 118.750  
RWY 10/28 - 118.100  
RWY 11R/29L - 125.850  
RWY 11L/29R - 123.825

SMC NORTH - 121.750  
MIDDLE - 121.900  
WEST - 119.575/SOUTH - 121.625



CLD 121.950 DVOR DPN 116.100 INDIA-DELHI/IGI AIRPORT  
DCL DELCFYA DVOR DIG 114.600

LEGEND

	RUNWAY HOLDING POSITION
	INTERMEDIATE HOLDING POSITION LIGHTS AND MARKING
	INTERMEDIATE HOLDING POSITION MARKING ONLY
	STOP BAR
	NO ENTRY BAR
	BOUNDARIES OF TOWER/SMC FREQUENCY
	DVOR/DME
	RUNWAY VISUAL RANGE
	VOR CHECK POINTS
	WIND DIRECTION INDICATOR
	ARRIVAL RWY 11R
	DEPARTURE RWY 11L
	DEPARTURE RWY 10

DATUM : WGS 84  
ELEVATION ARE IN FEET  
DIMENSIONS ARE IN METERS  
BEARINGS ARE MAGNETIC  
GEOID MODEL – EGM 2008

RUNWAY PAVEMENT  
FLEXIBLE  
RIGID



CAUTION :

1. BE ALERT FOR CLOSELY SPACED PARALLEL RUNWAY 11L/29R AND 11R/29L.
2. BE ALERT TO RUNWAY CROSSING CLEARANCES ON RWY 11L/29R AFTER LANDING ON 11R/29L. READBACK OF ALL RUNWAY HOLDING INSTRUCTIONS ARE REQUIRED.
3. AFTER LANDING ON RUNWAY 11R/29L, FOLLOW PRINCIPLE OF "LAND, VACATE, HOLD AND PROCEED". LAND ON RUNWAY 11R/29L, VACATE RUNWAY BY MAINTAINING LEAST ROT, HOLD AT RUNWAY HOLDING POINT OF RUNWAY 11L/29R, PROCEED WHEN CLEARED BY ATC FOR RUNWAY CROSSING.
4. PILOTS SHOULD BE EXTRA CAUTIOUS WHILE ENTERING EASTERN LINK TAXIWAYS FOR CORRECT TAXIWAY AND READ BACK OF TAXI INSTRUCTIONS.

CHART UPDATED ON 09MAY2024

PRODUCING ORGANIZATION : DELHI INTERNATIONAL AIRPORT LIMITED  
(DIAL-AIRSIDE-PLANNING@gmrgroup.in)