


図面／規格
【Belleville spring L (light (0chiai))】



単位 mm

サイズNo.	d		D		L(軽荷重用)			
	基本寸法	公差	基本寸法	公差	t		h (約)	h+t (約)
DB- 4L	4.2	+0.3 -0.1	8	±0.3	0.3	±0.025	0.25	0.55
DB- 5L	5.2		10		0.4	±0.03	0.3	0.7
DB- 6L	6.2		12.5		0.5		0.35	0.85
DB- 7L	7.2		14		0.5		0.4	0.9
DB- 8L	8.2		16		0.6	±0.04	0.45	1.05
DB- 9L	9.2	+0.4 -0.1	18	±0.4	0.7		0.5	1.2
DB-10L	10.2		20		0.8		0.55	1.35
DB-11L	11.2		22.5		0.8	±0.05	0.65	1.45
DB-12L	12.2		25		0.9		0.7	1.6
DB-14L	14.2		28		1		0.8	1.8
DB-16L	16.3	+0.5 -0.2	31.5	±0.5	1.2	±0.06	0.9	2.1
DB-18L	18.3		35.5		1.2		1	2.2
DB-20L	20.4		40		1.5		1.15	2.65
DB-22L	22.4		45		1.75	±0.07	1.3	3.05
DB-25L	25.4		50		2		1.4	3.4
DB-28L	28.5	+0.6 -0.4	56	±0.6	2		1.6	3.6
DB-30L	31		63		2.5	±0.08	1.75	4.25
DB-35L	36		71		2.5		2	4.5
DB-40L	41		80		3	±0.09	2.3	5.3
DB-45L	46		91		3.5		2.5	6
DB-50L	51	±0.7	100	±0.7	3.5		2.8	6.3