




SW24
SW_Push

RST GND

Left Encoder



SW4
RotaryEncoder_Switch_MP


col3 S1
E2S1 S2

A
C
B
GND

100nF C3
100nF C4

E2A
GND
E2B

Right Encoder



Schematic diagram of the SW25 SW_SPST switch component. The component has three pins: Pin 1 is connected to GND, Pin 2 is connected to J1 Conn_01x02, and Pin 3 is connected to RAW.

Battery Connector

Id: 1/1