

Step 1



Begin by selecting the bottom frame leg and the small ring. Spread the frame apart and position ring holes with frame holes.

Step 2



Using two of the long bolts and two nuts, insert and lightly hand tighten, one on each side.

Step 3



Slide the top frame over the top of the already assembled bottom frame leg and small ring and using two more long bolts and two nuts, insert and lightly hand tighten on the two remaining sides.

Step 4



Slide the large frame ring over the top of the already assembled parts, align bolt holes and lightly hand tighten with the remaining 4 long bolts and 4 nuts.

Step 5



Align bolt holes in top of frame legs and insert the short bolt (G) and using one of the nuts.

Step 6



Tighten all nuts and bolts using a Phillips screw driver.

Step 7



Offset the top swivel plate from the bottom plate to gain access to the bottom bolt holes and align with holes in the frame legs. Insert the 4 medium bolts and secure with the 4 remaining nuts. Tighten with Phillips screw driver.

Step 8




Turn assembled frame upside down and place on top of upside down pad. With swivel plates offset to allow access to the remaining bolts holes, insert the 4 brass bolts and tighten with Phillips screw driver.

Step 9


Enjoy!





CONTENTS

- A. 1x Top Pad
- B. 2x Frame Legs
- C. 2x Frame Rings
- D. 1x Swivel Plate
- E. 8x Long Bolts
- F. 4x Medium Bolts
- G. 1x Short Bolt
- H. 4x Brass Bolts
- I. 13x Nuts



CARE

Use a damp cloth to clean.
Do not use chemicals.