

RACING CAR



The Racing Car is suitable for home entertainment(Free play mode), and in bar, game room for coin business(Coin operation mode).

Contents

1. Description	
2. Switching On The Machine	
3. Game Description	
4. Coin machine	
5. Adjust Audio Volume	
6. Screen Adjustment	
7. Stabilising Feet	
8. Troubleshooting	

Before using this equipment please must understand all buttons function, see below picture explanation :



1. Description

- 32 “ LED high definition screen
- 4mm tempered glass to protect the screen.
- 107 games in one machine
- Size : 31.5" W x 58" L x 71" H.
- Weight : 110KG

2. Switching On The Machine

- Just simply plug in, turn on the button located on the rear door.
- It will take 30 seconds for loading.

3. Game Description

3.1 How to select a game ?

- Move the steering wheel left / right to select a game.

3.2 How to enter the game ?

- After you select a game, then press “Player One” button to enter the game, and then insert a coin or press “Coin ” button to get credit. Then start the game. (Kindly note that some games like “Daytona US” require you to press the gas pedal to confirm your selection)

3.3 How to Exit the game ?

- Press “Quit” button, the system will bring you back to main game menu.

3.4 What is the Gear Shifter for ?

- Some games like “Daytona US” have Manual game for option, you can use steering wheel to select this option, and then use Gear shifter to play for more fun.

3.5 Do the game support link function ?

- Yes, Some games like “Daytona US” support 2 machine link together to play against each other. We put a web cable into machine package. Just one end of web cable connect to 1 machine mother board, the other end of web cable connect to second machine mother board . Then link function is OK.

4. Coin machine

- To Setup coin Type enter \$1.00 coin or any other coin in the slot under the Yellow sticker.
- This mechanism where the stick is located will move up and you can slot the coin under the mechanism. This is a counter balance detector and what ever you coin you put in this slot is what the machine will detect and accept.



5. Adjust Audio Volume

- Use the key to open the coin acceptor door.
- You can access to the Amplifier to adjust the sound



6. Screen Adjustment

- Power machine on. Open rear access door and locate the row of five buttons on the side and rear of the screen.
- Buttons are: Top (nearest) = Menu & Enter. 2nd button = Cycle menu down. 3rd button = Cycle menu up. 4th button= Exit Menu. 5th button = Screen power on/off.
- Use buttons to adjust the screen preferences to your requirements. Use button 4 to exit the menu. Close the rear door.



7. Stabilising Feet

- Stabilise the machine by screwing down the feet in the bottom of the cabinet.
- Remember to retract the feet before moving the machine.



8. Troubleshooting

8.1 The steering wheel don't work / No action ?

- When you turn on the racing machine, the system will detect the steering wheel, and the steering wheel will turn around automatically. If the steering wheel has no action, then it proves that there is no power to the steering wheel. Please check the power cord and USB cable to the black mother board whether they are loose. If all cables connect well, please contact us.

Thank you and Enjoy the games !!