







entire_group (135)





prespore (48)





PstAO SSH475 pattern (18)





PstAO SSA854 pattern (5)





SLC388 pattern (1)





PstO SSM184 pattern (4)





PstO SLH659 pattern (15)





PstO SLG775 pattern (5)





PstA (2)





PstAO SLE474 pattern (6)





PstAB SSK348 pattern (2)





PstAB SSB312 pattern (3)





PstAB SLC388 pattern (1)



PstAB SLA128 pattern (3)



Late prestalk SSG721 pattern (9)



Late prestalk SSE634 pattern (13)

