


Position of Parts in Instrument Panel



C 6 Cigarette Lighter
C 7 Cigarette Lighter Illumination
C 8 Clearance Warning Buzzer
C 9 Clock
C 10 Combination Meter
C 11 Combination Meter
C 12 Combination SW
C 13 Combination SW
C 14 Combination SW

D 3 DLC3

E 9 Engine ECU
E 10 Engine ECU
E 11 Engine ECU
E 12 Engine ECU

H 5 Hazard Warning Signal SW

I 8 Ignition Key Cylinder Lamp
I 9 Ignition SW

Position of Parts in Instrument Panel

