




**RADIATOR SIDE SUPPORT (ASSY)****REPLACEMENT**


F21116A

**REMOVAL**

F21116

**INSTALLATION**

- Temporarily install the new parts and measure each part of the new parts in accordance with the body dimension diagram. (See the body dimension diagram)
- Inspect the fitting of the related parts around the new parts before welding. This affects the appearance of the finish.
- After welding, apply the polyurethane foam to the corresponding parts.
- After welding, apply body sealer and under-coating to the corresponding parts.
- After applying the top coat layer, apply anti-rust agent to the inside of the necked section structural weld spots.





F21117

**POINT**

- 1 Inspect the fitting of the headlight and front fender, etc., before welding, since this affects the appearance of the finish.

**PART NAME**

[A] Radiator Support To Front Fender Bracket      [B] Front End Panel No.1 Bracket



F21118

**POINT**

- 1 Measure the dimensions before installing the headlight.
- 2 These values are reference values.

106 mm (4.17 in.)

396 mm (15.59 in.)

730 mm (28.74 in.)

1,002 mm (39.45 in.)