



## Contactor Driver Version History

Helps pre-charge the contactors and controls the contactors for high voltage components.



Holes should be 39.7mm x 21.4mm where the 39.7mm edge is the direction the lead is facing  
HS50

### Precharge Resistor Mounts



### Board Mounts

