


INSTRUMENT PANEL (4SPTC BS-III)



All indicators may not be provided on some instrument cluster and may not be applicable to all models.