

## CONTENTS

<b>FOREWORD</b>	<b>5</b>	Driving Controls	28	Gear Shift Lever	49
<b>ENVIRONMENT PROTECTION</b>	<b>6</b>	Instrument Panel	29	Parking Brake Lever	49
<b>WARRANTY TERMS &amp; CONDITION</b>	<b>8</b>	Indicators	31	Bonnet Opening & Closing	50
<b>DO'S</b>	<b>10</b>	Gauges	34	Fuel Filling Cap Opening	50
<b>DONT'S</b>	<b>13</b>	Steering Lock Cum Ignition Switch	37	Spare Wheel	52
<b>HANDLING</b>	<b>16</b>	Combi-Switch	39	Vehicle Jack & Tools	53
Aggregate Numbering	16	Music System with USB & Blue Tooth	41	Catalytic Converter	54
Key	18	Antenna	41	EGR System	54
Anti-theft Device	18	Micro Phone	41	Turbocharger	55
Door Locking	19	Engine Compartment Lamp	41	Power Steering	56
Manual Window Winding	19	Tail Lamp	42	Air Conditioning	58
Power Windows	20	Registration Plate lamp	42	Roof AC	61
Sun Visors	21	High Mounted Stop Lamp	42	Preparing the vehicle for the drive	62
Outer Rear View Mirrors	22	Interior Roof Lamps	43	<b>DRIVING INSTRUCTION</b>	
Inner Rear View Mirror	22	Headlamp Leveling Switch	44	Driving Instruction	65
Driver's & Co-driver's Seat	23	Accessory Switches	45	Braking	66
Middle Seat	24	Power Socket	47	Fuel Economy	66
Seats at Rear	24	Mobile Holder	47	Driving in Adverse Conditions	67
Seat Belt	25	Grab Handle	48	Towing the Vehicle	70
Adjustable Head Restraint	27	Glove Box with Cup Holder	48	Driving Safety	71
				Safety Checks	72