



Fasten the tail boom to the tail fin using M5x35mm bolts, nuts and washers.