



Line up the angle iron straight down the pipe and use the holes in the angle iron to drill two more holes in the PVC pipe.

Fasten down the other end of the angle iron with another M5 nut, bolt and washer. Make sure the angle iron is straight and the bolts are tight.