


M16 Nut



Fasten the whole blade assembly together, until really tight, using superglue or threadlock to hold the fasteners in place.