


1:2



A
1:1

Screw the 15mm pipe into the flange as tight as possible. Note that the bolts will prevent the flange from sitting on the PVC, but this isn't a problem!