




# Alarm Help - MV SERIES -



ALARM ADDRESS	A9.4	ALARM NO.	1160
ALARM TEXT	CTS. PUMP O.L.		
Related Signal	Input: X7.2 (MV154/154APC/MV204) , X9.5 (184C) ◦ Output: Y0.2 (MV154/154APC/MV204) , Y5.4 (184C) ◦		
CAUSE	C.T.S. Pump breaker is overload ◦		
	<div><p>C.T.S. Pump</p></div> <div></div>		
ACTION	Turn on the breaker at cabinet as attached label indicated. ◦		
	Cancel alarm by reset button		on FANUC panel ◦