




ALARM ADDRESS	A10.2	ALARM NO.	1166
ALARM TEXT	ATC-ARM MOTOR OL.		
Related Signal	Input: X7.5 (MV154/154APC/MV204) , X9.7 (184C) ° Output: Y1.0 , Y1.1 (MV154/154APC/MV204) , Y4.6 , Y4.7(184C) °		
CAUSE	ATC-ARM Motor breaker is overload ° <div style="display: flex; justify-content: space-around; align-items: center;">   </div>		
ACTION	Turn on the breaker at cabinet as attached label indicated. ° <div style="display: flex; align-items: center; justify-content: center;">  <div style="margin-left: 10px;">             Cancel alarm by reset button on FANUC panel °           </div> </div>		