

## Alarm Help - MV SERIES -



ALARM ADDRESS	A9.6	ALARM NO.	1162
ALARM TEXT	OIL SKIMMER MOTOR OL		
Related Signal			
CAUSE	Breaker trip		
ACTION	1.check 3 phase voltage, and voltage phase to phase. 2.wiring loose. 3.check output relay.		