

ALARM ADDRESS	A12.7	ALARM NO.	1187
ALARM TEXT	NOW => ATC-ARM NOT INPOS.		
Related Signal	Input: X0.4 ,X0.5 , X0.6 , X0.7 (MV154/154APC/MV204) , X6.4 ,X6.5 ,X6.6 ,X6.7(184C) °		
CAUSE	In ATC service mode, ARM not at 0D & 60D & Bottom position, this message occurred °		
ACTION			