



# VIMBMW

VIDEO IN MOTION

BMW 3/5/7/X5

With TV Tuner

NAV TV (Europe) LTD



## NAV TV (Europe) LTD

Distribution Centre  
Unit 21B Vale Business Park  
Llandow, Vale of Glamorgan  
CF71 7PF

Telephone: + 44 (0)8445 783 783  
Fax: + 44 (0)1446 77 22 47  
technical@nav.tv

**Disclaimer**  
NAV TV (Europe) Ltd is not liable for any incidental, consequential or indirect damages. In case of erratic behavior of the vehicle's electrical system please disconnect the NAV TV product and contact our technical support Team. NAV TV (Europe) Ltd does not assume liability for any diagnostic fees.

e11\*72/245\*2004/104\*4020\*00  
RoHS 2002/95/EC—2002/96/EC

## LOCATION & REMOVAL

Installation is made at the factory TV Tuner,  
Locate TV Tuner box in rear of vehicle:



*E39 5 Series*



*E38 7 Series*



*E46 3 Series Convertible*



*E46 3 Series Saloon/Coupe*




*E53 X5*


## INSTALLATION

Locate the TV Tuner,

Locate the **Blue plug** and remove it from the factory tuner.




Next remove the **Blue outer casing** from the factory blue plug harness.



Then fit the supplied **Black outer casing** and locking slide to the factory harness.

Next fit the factory **Blue outer casing** to the supplied VIMBMW.



Now you are able to insert the **black plug** to the **black socket** and **blue plug** to the **blue socket**.



## OPERATING INSTRUCTIONS

The VIMBMW has a feature that enables you to activate and de-activate the “video in Motion” feature by pressing and holding the Auto reverse button (circled below) for 3 seconds.

The VIMBMW also enables you to switch between audio sources. Using the same auto reverse button, when pressed the system will revert back to the previous audio source used. For example; if when listening to radio you switch to TV to listen and view TV when the Auto reverse button is pressed the system will revert back to radio audio whilst viewing TV picture.

Lastly the VIMBMW will enable you to use your steering wheel controls (Track up and track down) to scroll TV tuner channels when the “program” banner is displayed.

