


Instructions

How to learn from the door opener:

1. Press the LEARN button on the opener over 2 seconds and the opener screen will show steady like '▪', then release the button.



2. Press the remote control button you wish for twice, the door opener screen will show 'H', indicating that you've successfully learn the program.

3. Press the remote control button again the door will be active.

How to clear the code:

Press the opener 'LEARN' button for 5 seconds. The the door opener screen will change from '▪' to 'H', indicating that you've successfully clear the code.

