











BARUN AWESOME COFFEE ROASTER



START

COOLING AGITATOR

STOP

START

COOLING FAN

STOP

START

DRUM

STOP

START

ROAST FAN

STOP

DRUM SPEED RPM

ROAST FAN SPEED RPM

ELAPSED TIME
MM:SS

START / PAUSE

STOP / RESET

HIGH TEMP CUT OUT

BARUN AWESOME COFFEE ROASTER