

Sheet: /LS/  
File: LS4.kicad\_sch

**Title:**

Size: A4


Date:

KiCad E.D.A. 8.0.9

**Rev:**

Id: 3/6

Remove R20–R22, R26–R28, and install Q7–Q12 for use with dumb coils



Sheet: /Ignition/  
File: IGN6.kicad\_sch

**Title:**


Size: A4

Date:

KiCad E.D.A. 8.0.9

**Rev:**

Id: 5/6



Sheet: /Injector/  
File: INJ6.kicad\_sch

**Title:**


Size: A4


Date:

KiCad E.D.A. 8.0.9

**Rev:**

Id: 6/6





NUP2105L is optional, used for protection

Sheet: /EGT/ File: egt.kicad_sch		
<b>Title:</b>		
Size: A4	Date:	Rev:
KiCad E.D.A. 8.0.9	Id: 9/6	