

# **Requirements document**

SQUID

Helsinki 21st February 2005  
Software Engineering Project  
UNIVERSITY OF HELSINKI  
Department of Computer Science

**Course**

581260 Software Engineering Project (6 cr)

**Project Group**

Mikko Jormalainen

Samuli Kaipainen

Aki Korpua

Esko Luontola

Aki Sysmäläinen

**Client**

Lauri J. Pesonen

**Project Masters**

Juha Taina

Jenni Valorinta

**Homepage**

<http://www.cs.helsinki.fi/group/squid/>

**Change Log**

Version	Date	Modifications
0.1	9.2.2005	First version (Aki Sysmäläinen)

# Contents

<b>1</b>	<b>Introduction</b>	<b>1</b>
1.1	Glossary . . . . .	1
<b>2</b>	<b>Overview</b>	<b>1</b>
<b>3</b>	<b>User requirements definition</b>	<b>1</b>
3.1	Requirements . . . . .	1
3.2	Restrictions . . . . .	1
<b>4</b>	<b>System requirements specification</b>	<b>1</b>
4.1	Functional requirements . . . . .	2
4.2	Non-functional requirements . . . . .	2
4.2.1	Environment . . . . .	2
4.2.2	Maintainability . . . . .	2
4.2.3	Etc. . . . .	2
4.2.4	Etc. . . . .	2
4.3	External interfaces . . . . .	2
4.4	System restrictions . . . . .	2
<b>5</b>	<b>Use cases</b>	<b>2</b>
5.1	Measuring . . . . .	2
5.1.1	Do single step measuring without demagnetization . . . . .	2
5.1.2	Do single step measuring with demagnetization . . . . .	2
5.1.3	Do automatic demagnetization-measuring sequence . . . . .	3
5.1.4	Do thellier measuring . . . . .	3
5.1.5	Do thermal measuring . . . . .	3
5.1.6	Measure magnetometer ground noise . . . . .	4
5.1.7	Measure empty sample holder noise . . . . .	4
5.1.8	Fully manual measuring . . . . .	4
5.2	File formats . . . . .	5
5.2.1	Automatically save all measurement cycles in project (.dat?) file . . . . .	5
5.2.2	Save standard sample measurement results in .std file . . . . .	5
5.2.3	Export (thellier) results into .tdt file . . . . .	5

5.2.4	Export single measurement details into .srm file . . . . .	5
5.2.5	Print measurement results . . . . .	5
5.2.6	Print graph sheet (with 7 different graphs; described elsewhere) .	5
5.3	Functionality . . . . .	5
5.3.1	Create new project (.dat file?) . . . . .	5
5.3.2	Load project (.dat file?) . . . . .	5
5.3.3	Append measurement results to project (.dat file?) . . . . .	5
5.3.4	Panic abort operation instantly . . . . .	5
5.4	AF sequences . . . . .	5
5.4.1	Insert AF sequence with start-step-stop values . . . . .	6
5.4.2	Load AF sequence . . . . .	6
5.4.3	Save AF sequence . . . . .	6
5.4.4	Edit AF sequence on-the-fly . . . . .	6
5.4.5	Edit stored AF sequences . . . . .	6
5.4.6	Rename stored AF sequence . . . . .	6
5.4.7	Delete stored AF sequence . . . . .	6
<b>6</b>	<b>User interface</b>	<b>6</b>
<b>7</b>	<b>Architecture overview</b>	<b>6</b>
<b>8</b>	<b>Validation</b>	<b>6</b>

# **1 Introduction**

This document describes client requirements and system requirements for a SQUID magnetometer program that will be designed and implemented as a software engineering student project at University of Helsinki at the Computer Science Department. The client is the Department of Geophysics.

This document serves as a contract between client and us..

Expected readership of this document here..

## **1.1 Glossary**

Technical terms here..

# **2 Overview**

A brief overview of the problem domain..

# **3 User requirements definition**

Goals of the software set by client..

## **3.1 Requirements**

Requirements by client..

## **3.2 Restrictions**

Restrictions set by client..

# **4 System requirements specification**

Specific explanation of the functions to be implemented

## **4.1 Functional requirements**

## **4.2 Non-functional requirements**

Requirements concerning the quality and performance of the software..

### **4.2.1 Environment**

### **4.2.2 Maintainability**

### **4.2.3 Etc.**

### **4.2.4 Etc.**

## **4.3 External interfaces**

Interface to existing software and use of it described here..

## **4.4 System restrictions**

# **5 Use cases**

Describes planned use cases for the program. Derived from user interface prototype and requirements. All use cases are made by "the user" in program main screen, unless otherwise noted.

## **5.1 Measuring**

### **5.1.1 Do single step measuring without demagnetization**

Enter as next AF demagnetization step "0" or empty (default for new projects), meaning no demagnetization, and click "Single step".

**Precondition:** Open AF project, sample in sample holder.

**Postcondition:** Sample measured, results on screen.

**Error condition:** The program shall let the user know if something went wrong.

### **5.1.2 Do single step measuring with demagnetization**

Enter as next AF demag step anything greater than zero, and click "Single step".

**Precondition:** Open AF project, sample in sample holder.

**Postcondition:** Sample demagnetized (possibly ruined) and measured, results on screen.

**Error condition:** The program shall let the user know if something went wrong, and, should the demagnetization field not be coming down, warn user with an alarm sound :)

### 5.1.3 Do automatic demagnetization-measuring sequence

Enter the AF sequence (see 5.4 for ways to enter it) and click "Measure".

**Precondition:** Open AF project, sample in sample holder.

**Postcondition:** Sample demagnetized according to entered AF sequence (possibly ruined) and measured after each demagnetization, results on screen.

**Error condition:** The program shall let the user know if something went wrong, and, should the demagnetization field be uncalm, warn user with an alarm sound x)

- Pause automatic measuring sequence

While measure sequence is running, click "Pause".

**Precondition:** Ongoing measure sequence.

**Postcondition:** Measure sequence halts after current step is done, results on screen.

**Error condition:** Program tells if sequence can't be paused (and something has gone terribly wrong).

- Abort automatic measuring sequence

While measure sequence is running or paused, click "Stop immediately".

**Precondition:** Ongoing or paused measure sequence.

**Postcondition:** Measure sequence halts immediately [and program enters "fully manual" mode?]

**Error condition:** Program tells if sequence can't be aborted (and something has gone terribly wrong).

### 5.1.4 Do thellier measuring

Click "Single step". (Temperature can be entered later, as it won't affect measuring.)

**Precondition:** Open TH project, sample in sample holder.

**Postcondition:** Sample measured, results on screen.

**Error condition:** As usual.

### 5.1.5 Do thermal measuring

[Exactly the same as thellier?]

Click "Single step". (Temperature can be entered later, as it won't affect measuring.)

**Precondition:** Open TH project, sample in sample holder.

**Postcondition:** Sample measured, results on screen.

**Error condition:** As usual.

### 5.1.6 Measure magnetometer ground noise

Click "Noise" and "Calibrate".

**Precondition:** None.

**Postcondition:** [Sample holder at home?] Ground noise measured, results on screen.

**Error condition:** As usual.

### 5.1.7 Measure empty sample holder noise

[2005-02-21 In current UI prototype, "Noise" actually does sample holder noise measuring.]

Click "Holder noise" and "Calibrate".

**Precondition:** Empty sample holder.

**Postcondition:** [Sample holder at home?] Holder noise measured, results on screen.

**Error condition:** As usual.

### 5.1.8 Fully manual measuring

Click any of the manual control components [2005-02-21 at right third of UI proto].

**Precondition:** None.

**Postcondition:** Manual action done, result on screen.

**Error condition:** As usual.

- Move sample handler to desired position
- Rotate sample handler to desired angle
- Measure in current position
- Demagnetize in current position



## 5.2 File formats

5.2.1 Automatically save all measurement cycles in project (.dat?) file

5.2.2 Save standard sample measurement results in .std file

5.2.3 Export (thellier) results into .tdt file

5.2.4 Export single measurement details into .srm file

5.2.5 Print measurement results

5.2.6 Print graph sheet (with 7 different graphs; described elsewhere)

## 5.3 Functionality

5.3.1 Create new project (.dat file?)

5.3.2 Load project (.dat file?)

5.3.3 Append measurement results to project (.dat file?)

5.3.4 Panic abort operation instantly

When any measuring action, click "Stop immediately".

**Precondition:** Single step measuring or ongoing measure sequence.

**Postcondition:** All demagnetization and measuring halts immediately [and program enters "fully manual" mode?]

**Error condition:** Program tells if measuring can't be aborted, meaning something has gone terribly wrong.

## 5.4 AF sequences

*As in automatic demagnetization-measuring sequences, or Alternating Field sequences*

**5.4.1 Insert AF sequence with start-step-stop values**

**5.4.2 Load AF sequence**

**5.4.3 Save AF sequence**

**5.4.4 Edit AF sequence on-the-fly**

**5.4.5 Edit stored AF sequences**

**5.4.6 Rename stored AF sequence**

**5.4.7 Delete stored AF sequence**

## **6 User interface**

Overview of UI described here..

## **7 Architecture overview**

## **8 Validation**

Description of how to validate the set requirements.